

**Smarter
Timing
Solutions**

EndRun TECHNOLOGIES

Præcis Cntp Network Time Server

User's Manual

Præcis Cntp Network Time Server

User's Manual

© EndRun Technologies
1360 North Dutton Avenue #200
Santa Rosa, California USA 95401
Phone 707-573-8633 • Fax 707-573-8619

Preface

Thank you for purchasing the Præcis Cntp Network Time Server. Our goal in developing this product is to bring precise, Universal Coordinated Time (UTC) into your network quickly, easily and reliably. Your new Præcis Cntp is fabricated using the highest quality materials and manufacturing processes available today, and will give you years of troublefree service.

About EndRun Technologies

Founded in 1998 and headquartered in Santa Rosa, California, we are the leaders in the exciting new time and frequency distribution technology based on the Code Division Multiple Access (CDMA) mobile telecommunications infrastructure. Our innovative designs and painstaking attention to the details of efficient manufacturability have made us the first to bring this technology to the broad synchronization market at prices small businesses can afford.

EndRun Technologies markets this technology in three major product lines:

Network Time Sources/Servers – These units are configured for optimum performance in operation with network servers/networks running the Internet protocol known as the Network Time Protocol (NTP).

Instrumentation Time and Frequency References – These products provide UTC traceable time and frequency signals for use in precision test and measurement instrumentation.

OEM Time and Frequency Engines – These products provide the core time and frequency capabilities to our customers who require lower cost and tighter integration with their own products.

About this manual

This manual will guide you through simple installation and set up procedures.

Introduction – The Præcis Cntp, how it works, where to use it, its main features.

Basic Installation – How to connect, configure and test your Præcis Cntp with your network.

Client Set-Up – Two sections; one for Unix-like platforms and one for Windows NT/2000.

If you detect any inaccuracies or omissions, please inform us. EndRun Technologies cannot be held responsible for any technical or typographical errors and reserves the right to make changes to the product and manuals without prior notice.

Trademark acknowledgements

IBM-PC, Linux, NotePad, Timeserv, UNIX, Windows NT/2000, WordStar are registered trademarks of the respective holders.

Præcis Cntp User's Manual

Revision 4

Part No. USM3007-0000-000

Jun 2003

Copyright © EndRun Technologies 2003

Warranty

This product, manufactured by EndRun Technologies, is warranted against defects in material and workmanship for a period of two years from date of shipment, under normal use and service. During the warranty period, EndRun Technologies will repair or replace products which prove to be defective.

For warranty service or repair, this product must be returned to EndRun Technologies. Buyer shall prepay shipping charges to EndRun Technologies and EndRun Technologies shall pay shipping charges to return the product to Buyer. However, Buyer shall pay all shipping charges, duties, and taxes for products returned to EndRun Technologies from another country.

Products not manufactured by EndRun Technologies but included as an integral part of a system (e.g. peripherals, options) are warranted for ninety days, or longer as provided by the original equipment manufacturer, from date of shipment.

Extended Warranty

The standard warranty may be extended beyond the standard two-year period. A record of warranty extensions is documented on the sales order for the product purchased. All other conditions of the standard warranty apply for the extended period.

Limitation of Warranty

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by Buyer, Buyer-supplied software or interfacing, unauthorized modification or misuse, operation outside of the environmental specifications for the product, or improper site preparation or maintenance.

NO OTHER WARRANTY IS EXPRESSED OR IMPLIED. ENDRUN TECHNOLOGIES SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Warranty Repair

If you believe your equipment is in need of repair, call EndRun Technologies and ask for a customer service agent. It is important to contact us first as many problems may be resolved with a phone call. Please have the serial number of the unit and the nature of the problem available before you call. If it is determined that your equipment will require service, we will issue an RMA number. You will be asked for contact information, including your name, address, phone number and e-mail address.

Ship the unit prepaid in the original container or a container of sufficient strength and protection to EndRun Technologies at the address shown below. EndRun will not be responsible for damage incurred during shipping to us. Be sure the RMA number is clearly identified on the shipping container. Our policy is to fix or repair the unit within 5 business days. If it is necessary to order parts or if other circumstances arise that require more than 5 days, an EndRun service technician will contact you.

Repair After Warranty Expiration

If the warranty period has expired, we offer repair services for equipment you have purchased from EndRun. Call and ask for a customer service agent. It is important to contact us first as many problems may be resolved with a phone call. Please have the serial number of the unit and the nature of the problem available before you call. If it is determined that the equipment has failed and you want EndRun to perform the repairs, we will issue you an RMA number. Ship the unit prepaid in the original container or a container of sufficient strength and protection to EndRun Technologies at the address shown below. EndRun will not be responsible for damage incurred during shipping to us. Customer is responsible for shipping costs to and from EndRun Technologies. Be sure the RMA number is clearly identified on the shipping container. After the equipment has been received we will evaluate the nature of the problem and contact you with the cost to repair (parts and labor) and an estimate of the time necessary to complete the work.

Limitation of Liability

The remedies provided herein are Buyer's sole and exclusive remedies. EndRun Technologies shall not be liable for any direct, indirect, special, incidental or consequential damages, whether based on contract, tort or any other legal theory.

Table of Contents

Introduction		1
CDMA Timing—How it Works		1
Where to Use It		3
Main Features		3
Basic Installation		5
Checking and Identifying the Hardware		5
Præcis Cntp Physical Description		6
Performing an Initial Site Survey		7
Installing the Præcis Cntp		8
Mount the Præcis Cntp	8	
Connecting and Configuring Ethernet	8	
Connect the RS-232 Serial I/O Port	9	
Test the Serial Port	9	
Using netconfig to Set Up Your IP	12	
Verify Network Configuration	14	
Check Network Operation	16	
Using Telnet	16	
Using SSH	17	
Configuring the Network Time Protocol		17
Setting Up NTP Clients on Unix-like Platforms		21
Basic NTP Client Setup		22
Configure NTP	22	
MD5 Authenticated NTP Client Setup		23
Create the ntp.keys file	23	
Configure NTP	24	
Broadcast/Multicast NTP Client Setup		25
Configure NTP	25	
Setting Up NTP Clients on Windows NT 4.0/2000		27
Basic NTP Client Setup		28
Configure NTP	28	
MD5 Authenticated NTP Client Setup		29
Create the ntp.keys file	29	
Configure NTP	30	
Broadcast/Multicast NTP Client Setup		31
Configure NTP	32	
Control and Status Commands		35
General Linux Shell Operation		35

Available User Commands		36
Detailed Command Descriptions		37
accessconfig	37	
cdmaleapconfig	38	
cdmaleapmode	38	
cdmastat	38	
cdmaversion	42	
cntpenableupgrade	42	
cntphwaddr	42	
cntpostype	42	
cntpasswd	42	
cntproofs	43	
cntpstat	43	
cntptimemode	44	
cntptimemodeconfig	45	
cntpversion	45	
inetdconfig	45	
netconfig	45	
ntpconfig	46	
updatelilo	46	
Time Figure of Merit		48
RS-232 Serial I/O Port Signal Definitions		49
Null Modem Adapter Cable		49
Upgrading the Firmware		51
What You Need To Perform the Upgrade		51
Performing the Præcis Cntp Upgrade		51
Recovering from a Failed Upgrade		53
Performing the CDMA Upgrade		54
Problems with the CDMA Upgrade		55
Simple Network Management Protocol		57
SNMPv3 Security	57	
Enterprise Management Information Base (MIB)	58	
Invocation of the SNMP daemon	58	
Quick Start Configuration – SNMPv1/v2c		59
Configuring SNMPv1 Trap Generation	59	
Configuring SNMPv2c Notifications and Informs	60	
Configuration of SNMPv3		60
Security		63
Linux Operating System		63
OpenSSH		65
Network Time Protocol		66
Lithium Battery Replacement		67
Specifications		69

Introduction

The Præcis Cntp is a precision server of Universal Coordinated Time (UTC) that can be connected via a 10/100Base-T ethernet port to any TCP/IP network. In its most basic operation, it sends Network Time Protocol (NTP)/Simple Network Time Protocol (SNTP) reply packets in response to NTP/SNTP request packets which it has received from clients. The timestamps it sends in its NTP/SNTP reply packets are accurate to less than one-hundred microseconds. NTP/SNTP client software is available for virtually all operating systems.

The Præcis Cntp is composed of a Præcis Cntp Code Division Multiple Access (CDMA) time and frequency engine, an IBM-PC compatible single board computer with fanless, convection-cooled 133 MHz CPU with integral ethernet interface, and a power supply. Non-volatile storage of the embedded Linux operating system and the Præcis Cntp application software on the single board computer is via a solid state FLASH disk.

For more detailed information that is not included in this manual, and links to other sites, please visit our website: <http://www.endruntechnologies.com>. There you can also download firmware upgrades, the latest manuals and other documentation.

CDMA Timing—How it Works

CDMA mobile telecommunications base stations must be synchronized.

The CDMA time and frequency engine in the Præcis Cntp receives transmissions from base stations, also known as cell sites, that are operating in compliance with the TIA/EIA IS-95 standard for Code Division Multiple Access (CDMA) mobile telecommunications. This system requires a means of synchronizing the base stations throughout the network so that neighboring cells do not interfere with each other and so that calls can be efficiently transferred between the base stations, without interruption, as the mobile user traverses the cell coverage areas. This ‘soft hand-off’ feature means that the mobile telephone must be able to ‘hitlessly’ drop one base station and pick up the next one. To do this, the telephone must be able to calculate the relative difference in

time between the codes that modulate the signals from each of the base stations, which again, requires that the base stations be synchronized.

Each base station contains at least one state-of-the-art GPS timing receiver with an ultra-stable local oscillator.

The system designers chose the Global Positioning System (GPS), which is itself a CDMA-based system, as the means of maintaining synchronization, and they defined *system time* to be *GPS time*. Each base station throughout the system contains one or more high-performance GPS timing receivers with sophisticated algorithms that control either an extremely stable ovenized quartz crystal oscillator or a Rubidium vapor atomic frequency standard. Such elaborate means are needed to meet the very difficult operating specifications required by the TIA/EIA IS-95 standard. The base station time synchronization must remain within 10 microseconds of GPS time over periods as long as twenty-four hours during which GPS satellite signals might not be available (typically due to antenna/cable failure, damage or vandalism) and in an environment where large ambient temperature swings may occur. Equipment capable of meeting these requirements is at the current state-of-the-art.

The base stations transmit a sync signal that all of the phones must use to establish and maintain system time.

The CDMA time and frequency engine in the Præcis Cntp receives the same initialization signals transmitted by the base stations that are used by the mobile telephones to establish their synchronization to system time. The mobile telephones cannot communicate in the system until they have established synchronization with the received spread spectrum encoded waveform. Unlike the mobile telephones, once this synchronization has occurred, the CDMA time and frequency engine in the Præcis Cntp has all of the information that it needs to perform its function of delivering accurate UTC time to a network of computers. The mobile telephone must decode much more information, establish two-way communications with the base station, and be a paid subscriber to perform its function of placing and receiving calls.

Spread spectrum modulation allows near perfect extraction of the timing information. We call it 'indirect GPS'.

All of this means that during normal operation, the quality of the timing information being transmitted from each of the base stations is virtually a repeat of that directly obtainable from the GPS. The big difference is that the received signal strengths from the base stations are a minimum of 30 dB larger than those from the GPS satellites, which is why you can usually talk on your cell phone indoors. Due to the nature of the IS-95 spread spectrum CDMA modulation scheme, this timing information may be extracted by a well-designed receiver with a precision of a few nanoseconds. The CDMA time and frequency engine in the Præcis Cntp does just that, and for this reason, we call our technology 'indirect GPS'.

Where to Use It

You must have cellular, IS-95 CDMA coverage.

First, the Præcis Cntp must be deployed in a *cellular* IS-95 CDMA coverage area. *Cellular* is a commonly used term implying that the frequency band for the base station carrier transmissions is 824-895 MHz. This is in contrast to *PCS*, which implies operation in the 1850-1990 MHz frequency band. The Præcis Cntp uses the cellular frequency band because it provides much better propagation characteristics in regards to building penetration and maximum receivable range from the transmitter. In general, if your cellular CDMA telephone works where you plan to install the Præcis Cntp, then your Præcis Cntp will work properly there.

Just about any computer network using TCP/IP can use the Præcis Cntp

Because the Præcis Cntp has been designed to operate in conjunction with existing public domain NTP/SNTP client software that has been created for use with similar time servers, it may be used in any computer network environment that is using TCP/IP protocols. Although client software is available for all platforms, for the most precise applications, the Unix-like operating systems are best supported.

Main Features

Performance, reliability and economy

The Præcis Cntp provides high performance and reliability combined with low power consumption and cost. Its internal sub-assemblies are fabricated using state-of-the-art components and processes and are integrated in a solid, high-quality chassis.

Flexibility

It supports a variety of TCP/IP network protocols compatible with a variety of platforms and operating systems.

Easy Installation

Its standard 1U high, 19" rack-mountable chassis and rooftop *or window-mounted* antenna make installation simpler compared to competing products that *require* rooftop installation of the antenna. The rack-mount chassis may be mounted in any convenient location. Connect it to your network via the rear panel mounted, 10/100Base-T RJ-45 connector and plug in the AC power cord. Initial network configuration is automatic on networks using the Dynamic Host Configuration Protocol (DHCP). Manual network configuration is via the RS-232 serial I/O port and a simple Linux shell script.

Free FLASH Upgrades

Firmware and configurable hardware parameters are stored in non-volatile FLASH memory, so the Præcis Cntp can be easily upgraded in the field using FTP and TELNET or the local RS-232 serial I/O port. Secure upgrades are possible via SSH and SCP. We make all firmware upgrades to our Præcis products available to our customers free of charge.

Basic Installation

This chapter will guide you through the most basic checkout and physical installation of your Præcis Cntp. Subsequent chapters and appendices will give you the information needed to configure your installation for the maximum performance in your operating environment. General NTP client setup instructions will also be supplied to get you started using your Præcis Cntp quickly.

Basic familiarity with TCP/IP networking protocols like **ping**, **telnet** and **ftp** is required. Though some familiarity with Linux or other Unix-like operating systems would be helpful, it is not essential. If you satisfy these conditions, the instructions provided herein should guide you to a successful installation without extensive gnashing of teeth.

Checking and Identifying the Hardware


Unpack and check all the items using the following check list. Contact the factory if anything is missing or damaged.

The Præcis Cntp Hardware Pack (part # 4003-0000-000 or # 4003- variant) contains:

- ❑ Præcis Cntp (part # 3007-0000-000 or # 3007- variant)
- ❑ Præcis Cntp User's Manual (part # USM3007-0000-000)
- ❑ IEC 320 AC Power Cord (part # 0501-0003-000)
- ❑ DB-9F to DB-9F Null Modem Serial I/O Cable (part # 0501-0002-000)
- ❑ RJ-45 to RJ-45 CAT-5 patch cable, 2 meters (part # 0501-0002-000)
- ❑ Magnetic mount antenna/cable assembly (part # 0502-0001)

Præcis Cntp Physical Description

Front Panel




- Lock Status LED** This green LED flashes to indicate synchronization status.

- Link Status LED** This amber LED illuminates when the 10/100Base-T RJ-45 connector is connected to the network.

- Link Activity LED** This amber LED illuminates when the Præcis Cntp is receiving or transmitting on the network.

- Alarm Status LED** This red LED illuminates briefly at power-up, and thereafter whenever a serious fault condition exists.

Rear Panel



- CDMA ANT. Jack** This SMA connector mates with the cable from the external, magnetic mount antenna.

- 1PPS Jack** This BNC connector provides the optional 1PPS TTL output.

- 10 MPPS Jack** This BNC connector provides the optional 10 MPPS TTL output.

- Timecode Jack** This BNC connector provides the optional IRIG-B time code output.

- 10 MHz, 5 MHz, 1 MHz, 5 MPPS, 1 MPPS, Time Code TTL Jacks** These BNC connectors are additional optional outputs and may or may not be present on your unit.

- RS-232 Serial I/O Jack** This DB-9M connector provides the RS-232 serial I/O console interface to the Præcis Cntp. This console allows the user to initialize and maintain the Præcis Cntp. A null modem adapter is required to connect this port to another computer.

10/100Base-T Jack	This RJ-45 connector mates with the ethernet twisted pair cable from the network.
AC Power Input Jack	This IEC 320 standard three-prong connector provides AC power.

Performing an Initial Site Survey

Using the status LED indicators, it's easy to find out if your Præcis Cntp will work in your desired location:

1. Screw the SMA plug on the end of the antenna cable onto the SMA antenna input jack on the chassis rear panel of the Præcis Cntp.
2. Plug one end of the supplied AC power cord into an 85-270 VAC outlet.
3. Plug the other end into the AC input connector on the chassis rear panel of the Præcis Cntp.

Place the antenna on a flat, preferably metallic surface while the unit is searching for the signal. Make sure that it is not blocked by large metallic objects closer than one meter. Although the antenna should normally be installed in a vertical orientation, usually multipath conditions due to signal reflections indoors cause at least some of the signal to be horizontally polarized, so do not be surprised if you find that the unit will work with the antenna oriented either way. Multipath conditions can also cause another effect: signal cancellation. Since the wavelength of the signal is only about thirty centimeters, movement of the antenna just a few centimeters can sometimes cause significant signal strength changes.

Initially upon power up:

1. The unit will light the red Alarm Status LED for about ten seconds.
2. Then it will continuously light the green Lock Status LED.
3. When the unit has detected a CDMA signal, the green Lock Status LED will begin to flash very slowly (about a .4 Hz rate).
4. As the unit locks onto the CDMA signal and begins to decode the timing data, the green Lock Status LED will flash very rapidly (about a 6 Hz rate) until the data is fully decoded.
5. Then the green Lock Status LED will pulse at precisely a 1 Hz rate, synchronized to UTC seconds, with a short on duration relative to the off duration.

At this point, the CDMA time and frequency engine has fully synchronized, and you may proceed to permanently mounting the chassis and antenna in the desired location.

If this sequence has not occurred within twenty minutes, you should move the antenna and/or change its orientation and re-try. If you are unable to find an antenna location where the unit will acquire the CDMA signals, you may not have coverage in your area or the signal might be too weak in your facility. You should continue to try for at least a day, however since base stations are taken down for service from time to time.

If you have a cellular CDMA phone, see if it will work in *digital* mode. If it will, then your Præcis Cntp may be damaged and should be returned to the factory for repair or exchange.

Installing the Præcis Cntp

Mount the Præcis Cntp

CAUTION

Ground the unit properly with the supplied power cord.

Position the power cord so that you can easily disconnect it from the Præcis Gntp.

Do not install the Præcis Gntp where the operating ambient temperature might exceed 122°F (50°C).

Using standard 19" rack mounting hardware, mount the unit in the previously surveyed location. Make sure that the antenna is not blocked by metallic objects that are closer than about one meter. A good location is the top surface of the equipment rack into which the unit has been installed. Ideally it should be mounted vertically, as the transmitted signals are vertically polarized. When indoors, however, multipath conditions may exist. This means that reflected signals may be present with either vertical or horizontal polarization, so your antenna might work in either orientation. After mounting the unit and antenna, verify that it still acquires and tracks a CDMA signal.

Connecting and Configuring Ethernet

Connect one end of the CAT-5 patch cable supplied with your Præcis Cntp to the rear panel mounted RJ-45 connector labeled 10/100BASE-T. Connect the other end of the patch cable to your network through a 'straight' port on your hub. Do not connect it to a 'crossover' port on your hub.

By factory default, the Præcis Cntp will attempt to configure the ethernet interface automatically via the Dynamic Host Configuration Protocol (DHCP). The Præcis Cntp will attempt to set the netmask, its IP address, the IP address of the default gateway, the domain name and the IP addresses of any nameservers, if the DHCP server is configured to provide them. You may optionally configure the Præcis Cntp to also set its hostname via DHCP, if your DHCP server is configured to provide it. You can do this by running a simple shell script called **netconfig** after your unit is up on the network.

If your network *does* use DHCP for host configuration, and you are in a hurry to get your Præcis Cntp up and running, you may proceed to *Verifying Network Configuration* to make sure that the network parameters were set up correctly. Otherwise, it is recommended that you read the following sections on use of the RS-232 serial I/O port now, since they will help you in debugging any problems that you may encounter with the automatic configuration via DHCP.

If your network *does not* use DHCP, you will need to configure your ethernet interface using the RS-232 serial I/O port. In that case, after logging in as the *root* user, you must run a simple shell script called **netconfig** from the **ash** shell prompt. This shell script will prompt you for the needed information and perform some syntax checking on your inputs. Then it will create or modify the appropriate files needed to configure the ethernet interface.

The following sections will guide you in setting up communications with the Præcis Cntp using its RS-232 serial I/O port.

Connect the RS-232 Serial I/O Port

You will need to use the RS-232 serial I/O port if your network does not support the Dynamic Host Configuration Protocol (DHCP). In that case, you must be able to configure the Præcis Cntp network parameters manually using the Linux console shell interface which is provided by this serial I/O port. Under certain conditions, you may also need to use the RS-232 serial I/O port if you encounter a problem while upgrading the firmware in your Præcis Cntp. To test serial communications with the Præcis Cntp you will need either a VT100 compatible terminal or a terminal emulation program running on your computer. We will refer to either of these as “terminal” for the remainder of this instruction.

1. Disconnect power from the Præcis Cntp.
2. Connect one end of the DB9F to DB9F null modem adapter cable to the serial I/O jack on the Præcis Cntp.
3. Connect the other end of the DB9F to DB9F null modem adapter cable to the terminal. If the serial I/O port on your terminal does not have a DB9M connector, you may need to use an adapter. Refer to Appendix A – *RS-232 Serial I/O Port Signal Definitions* for details on the signal wiring. *If you are using a computer for your terminal, remember which port you are using because you will need to know that in order to set up your terminal software.*

Test the Serial Port

You must configure your terminal to use the serial I/O port you used in *Connect the RS-232 Serial I/O Port*. You must also configure your terminal to use the correct baud rate,

number of data bits, parity type and number of stop bits. *Be sure to turn off any hardware or software handshaking.* The settings for the Præcis Cntp are:

- ❑ 19200 is the Baud Rate
- ❑ 8 is the number of Data Bits
- ❑ None is the Parity
- ❑ 1 is the number of Stop Bits

After configuring these parameters in your terminal, apply power to the Præcis Cntp. After about 20 seconds, your terminal should display a sequence of boot messages similar to these:

```
LILO
Low memory: 0262 Kb
boot:
```

These three lines are the Linux Loader (LILO) boot prompt. This prompt will timeout after 5 seconds and the Linux kernel and the factory default Præcis Cntp root file system will be loaded. When the Linux kernel is loaded from the FLASH disk into RAM a long list of kernel-generated, informational messages is displayed as the kernel begins execution and the various device drivers are initialized:

```
Loading PraecisCntp_1.....
Linux version 2.2.13-DOC (root@endrun1) (gcc version egcs-2.91.66 19990314/Linux
(egcs-1.1.2 release)) #8 Thu Dec 28 12:59:41 PST 2000
Calibrating delay loop... 66.56 BogoMIPS
Memory: 12960k/16384k available (564k kernel code, 440k reserved, 356k data, 28k
init)
Checking if this processor honours the WP bit even in supervisor mode... Ok.
CPU: AMD Am5x86-WB stepping 04
Checking 386/387 coupling... OK, FPU using exception 16 error reporting.
Checking 'hlt' instruction... OK.
POSIX conformance testing by UNIFIX
Linux NET4.0 for Linux 2.2
Based upon Swansea University Computer Society NET3.039
NET4: Unix domain sockets 1.0 for Linux NET4.0.
NET4: Linux TCP/IP 1.0 for NET4.0
IP Protocols: ICMP, UDP, TCP
Starting kswapd v 1.5
Serial driver version 4.27 with no serial options enabled
ttyS00 at 0x03f8 (irq = 4) is a 16550A
ttyS01 at 0x02f8 (irq = 3) is a 16550A
RAM disk driver initialized: 16 RAM disks of 8192K size
Flash disk driver for DiskOnChip2000
Copyright (C) 1998,2000 M-Systems Flash Disk Pioneers Ltd.
Copyright (C) 2000 Lineo
DOC device(s) found: 1
Fat Filter Enabled
ne.c:v1.10 9/23/94 Donald Becker (becker@cesdis.gsfc.nasa.gov)
NE*000 ethercard probe at 0x340: 00 d0 c9 11 33 41
eth0: NE2000 found at 0x340, using IRQ 10.
fl_geninit: registered device at major: 100
partition: 0: start_sect: 0, nr_sects: 3e30 Fl_blk_size[]: 1f18kb
partition: 1: start_sect: 0, nr_sects: 0 Fl_blk_size[]: 0kb
Partition check:
fla: fla1 fla2 fla3 fla4
RAMDISK: Compressed image found at block 0
```



```
VFS: Mounted root (ext2 filesystem).
Freeing unused kernel memory: 28k freed
INIT: version 2.76 booting
Parallelizing fsck version 1.15 (18-Jul-1999)
ext2fs_check_if_mount: No such file or directory while determining whether /dev/msys/
fla1 is mounted.
/dev/msys/fla1: clean, 29/80 files, 519/591 blocks
ext2fs_check_if_mount: No such file or directory while determining whether /dev/msys/
fla2 is mounted.
/dev/msys/fla2: clean, 15/32 files, 67/240 blocks
ext2fs_check_if_mount: No such file or directory while determining whether /dev/msys/
fla3 is mounted.
/dev/msys/fla3: clean, 12/448 files, 2117/3560 blocks
ext2fs_check_if_mount: No such file or directory while determining whether /dev/msys/
fla4 is mounted.
/dev/msys/fla4: clean, 12/448 files, 2117/3568 blocks
fla: fla1 fla2 fla3 fla4
/dev/msys/fla1 o fla:n /boot type ext fla12 (rw)
fla2 fla3 fla4 /dev/msys/fla1 o fla:n /boot type ext fla12 (rw)
fla2 fla3 fla4
/dev/msys/fla2 o fla:n /logs type ext fla12 (rw)
fla2 fla3 fla4
/dev/msys/fla3 o fla:n /rootfs_0 type fla1 ext2 (rw)
fla2 fla3 fla4
/dev/msys/fla4 on /rootfs_1 type ext2 (rw)
/proc on /proc type proc (rw)
hwclock: Can't open /dev/tty1, errno=19: No such device.
INIT: Entering runlevel: 3
Entering multiuser...
Attempting to configure eth0 by contacting a DHCP server...
```

At this point, if you do not have a DHCP server configured on your network the unit will time-out and print these messages:

```
Praecis Cntp DHCP Client was unable to find the DHCP Server!
Fix the problem and re-boot or set up static IP address
by running netconfig.
dnsdomainname: Host name lookup failure
(none)
```

Then these messages are printed, in either case.

```
Activating IPv4 packet forwarding...
Starting daemons: syslogd klogd inetd
Starting the Network Time Protocol daemon...
Starting the SNMP daemon...
Starting the system logfile manager...
Starting the system watchdog...woof!
```

During this process, the factory default PraecisCntp_0 root file system is loaded from FLASH disk to an 8MB ramdisk and the remainder of the boot process completes. At this point, the Praecis Cntp login prompt is displayed:

```
*****
*           Welcome to Praecis Cntp console on:  cntp.your.domain
*           Tue Feb 20 2001 21:47:03 UTC
*****

cntp login:
```

Here you may log in as “cntpuser” with password “Præcis” or as the “root” user with password “endrun_1”. When logged in as “cntpuser”, you may check status information and view log files but you will not be able to modify any system settings or view secure files. In order to perform system setup procedures, which includes configuring the IP network settings, you must log in as the “root” user. After correctly entering the password at this prompt,

password:

the sign on message is shown. It identifies the host system as Præcis Cntp and shows the software part number, version and build date:

```
Praecis Cntp 6010-0003-000 v 1.00 Wed May 9 14:17:44 UTC 2002
Praecis Cntp->
```

This last line is the standard Præcis Cntp shell prompt. The Præcis Cntp uses the **ash** shell, which is a reduced functionality, **bash**-compatible shell. After configuring the unit, you should change the passwords using the **cntppasswd** command issued from the shell prompt.

If you do not see characters displayed by your terminal program within 30 seconds after the unit is powered up, you must troubleshoot your setup. An incorrectly wired cable or incorrect port setting in your terminal emulation program are the most common problems. Refer to Appendix A – *RS-232 Serial I/O Port Signal Definitions* for the signal connections for the Præcis Cntp.

NOTE

You must use a null modem cable or adapter if you are connecting the Præcis Gntp to another computer or other equipment configured as Data Terminal Equipment (DTE). The supplied cable is a null modem cable.

Once you have successfully established communications with the Præcis Cntp, you may proceed to configuring the network parameters. Then you can communicate with the Præcis Cntp over the network using **telnet** or **ssh** and synchronize your network computers to UTC using NTP.

Using netconfig to Set Up Your IP

The following is a sample transcript which illustrates the use of **netconfig**. The entries made by the user are underlined and are provided purely for illustrative purposes. You must provide equivalent entries that are specific to your network. Those shown here are appropriate for a typical network that does not use DHCP. Start the configuration process by typing **netconfig** at the shell prompt:

```
Praecis Cntp-> netconfig
```

ENDRUN TECHNOLOGIES

```
*****
***** Praecis Cntp Network Configuration *****
*****
*
* This script will configure the TCP/IP network parameters for your
* Praecis Cntp. You will be able to reconfigure your system at any time
* by typing:
*
* netconfig
*
* The settings you make now will not take effect until you restart your
* Praecis Cntp, so if you make a mistake, just re-run this script before
* re-booting.
*
* You will be prompted to enter your network parameters now.
*
*****
*****
```

---DHCP Settings

Use a DHCP server to configure the ethernet interface? ([y]es, [n]o) n

---HOST name setting

Set the hostname of your Praecis Cntp. Only the base hostname is needed, not the domain.

Enter hostname: cntp

---DOMAIN name setting

Set the domain name. Do not supply a leading \.'

Enter domain name for cntp: your.domain

---STATIC IP ADDRESS setting

Set the IP address for the Praecis Cntp. Example: 111.112.113.114

Enter IP address for cntp (aaa.bbb.ccc.ddd): 192.168.1.245

---DEFAULT GATEWAY ADDRESS setting

Set the default gateway address, such as 111.112.113.1

If you don't have a gateway, just hit ENTER to continue.

Enter default gateway address (aaa.bbb.ccc.ddd): 192.168.1.241

---NETMASK setting

Set the netmask. This will look something like this: 255.255.255.0

Enter netmask (aaa.bbb.ccc.ddd): 255.255.255.248

Calculating the BROADCAST and NETWORK addresses...

Broadcast = 192.168.1.247 Network = 192.168.1.240

Your Praecis Cntp's current IP address, full hostname, and base hostname:

192.168.1.245 cntp.your.domain cntp

---DOMAIN NAMESERVER(S) address setting

Will your Praecis Cntp be accessing a nameserver ([y]es, [n]o)? y

Set the IP address of the primary name server to use for domain your.domain.

Enter primary name server IP address (aaa.bbb.ccc.ddd): 192.168.1.1

Will your Praecis Cntp be accessing a secondary nameserver ([y]es, [n]o)? y

Set the IP address of the secondary name server to use for domain `your.domain`.
 Enter secondary name server IP address (`aaa.bbb.ccc.ddd`): 192.168.1.2

```
Setting up TCP/IP...
Creating /etc/HOSTNAME...
Creating /etc/rc.d/rc.inet1...
Creating /etc/networks...
Creating /etc/hosts...
Creating /etc/resolv.conf...
```

```
*****
*****
*
*           The Praecis Cntp network configuration has been updated.
*
*           Please re-boot now for the changes to take effect.
*
*****
*****
*****
```

Verify Network Configuration

If you have made changes to your network configuration using `netconfig`, you should shutdown the Praecis Cntp and re-boot it. There are two ways to do this:

1. Cycle power to the Praecis Cntp.
2. Issue the shutdown with re-boot command at the shell prompt:

```
Praecis Cntp-> shutdown -r now
```

If you are using the RS-232 serial I/O port to communicate with the Praecis Cntp, you will be able to see the kernel generated boot messages when the unit re-boots. You should note the line

```
Configuring eth0 as 192.168.1.245...
```

if you have set up a static IP address, or this line

```
Attempting to configure eth0 by contacting a DHCP server...
```

if you are using DHCP. It appears near the end of the kernel generated boot messages.

If you are using DHCP and are not using the RS-232 serial I/O port, you will have to check the DHCP configuration information maintained by your DHCP server to determine the expected IP address and log in to the Praecis Cntp using `telnet` or `ssh` to verify successful DHCP configuration. Refer to the subsequent topics in this section *Using Telnet* and *Using SSH*, for details on logging in to the Praecis Cntp that way. Once you have logged in, you may perform the following checks.

If you are not using DHCP, the IP address shown should match the static IP address which you entered during the **netconfig** procedure. If so, log in as “root” at the login prompt and check the other configuration parameters using **ifconfig**:

Praecis Cntp-> ifconfig

```
eth0      Link encap:Ethernet  HWaddr 00:D0:C9:11:33:41
          inet addr: 192.168.1.245 Bcast:192.168.1.247 Mask:255.255.255.248
          UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
          RX packets:3779 errors:0 dropped:0 overruns:0 frame:0
          TX packets:727 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:100
          Interrupt:5 Base address:0x300

lo        Link encap:Local Loopback
          inet addr:127.0.0.1  Mask:255.0.0.0
          UP LOOPBACK RUNNING  MTU:3924  Metric:1
          RX packets:170 errors:0 dropped:0 overruns:0 frame:0
          TX packets:170 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:0
```

Pay particular attention to the settings shown for **eth0** and in particular the **Mask:** setting, which should match that which is appropriate for your network. Now check the remaining configuration parameters using **route**:

Praecis Cntp-> route

```
Kernel IP routing table
Destination Gateway      Genmask      Flags Metric Ref Use Iface
localnet   *                255.255.255.248  U      0      0  0 eth0
loopback   *                255.0.0.0      U      0      0  0 lo
default    192.168.1.241   0.0.0.0        UG     1      0  0 eth0
```

Here you are interested in the default gateway address. It should match the appropriate one for your network. If so, then the ethernet interface of your **Praecis Cntp** has been successfully configured to operate on your network and you are ready to check operation of the **Praecis Cntp** over the network. If not, you should re-check your configuration and/or repeat the **netconfig** procedure.

If you have configured a nameserver(s) for your network, you may check that by issuing this shell command:

Praecis Cntp-> cat /etc/resolv.conf

```
search your.domain
nameserver 192.168.1.1
nameserver 192.168.1.2
```

Which displays the contents of the */etc/resolv.conf* file containing your domain name and the nameserver IP address(es) to use for that domain.

Check Network Operation

With your Præcis Cntp network parameters properly configured, you are ready to test the setup using **ping** from a server or workstation that is able to access the network connected to the Præcis Cntp. Alternatively, you could **ping** one of your servers or workstations from the Præcis Cntp shell prompt to test the setup.

Once you have successfully established network communications with the Præcis Cntp, you may perform all maintenance and monitoring activities via **telnet** and **ftp**. The Præcis Cntp provides both client and server operation using **telnet**. For security reasons as well as to reduce the memory footprint in the Præcis Cntp, only client operation is supported using **ftp**.

Security conscious users will want to use **ssh**, the *secure shell* replacement for **telnet**, as the login means. The companion utility, **scp** provides a secure replacement for **ftp** as a means of transferring files to and from the Præcis Cntp. Both of these protocols are supported in the Præcis Cntp via the OpenSSH implementations for Linux. Refer to Appendix D – *Security* for more information about the *secure shell* protocol and its configuration.

Using Telnet

When establishing a **telnet** connection with your Præcis Cntp, logging in directly as *root* is not permitted. This is a security measure that makes it slightly more difficult to gain access by simply trying passwords, since it is also necessary to know the name of a user. When you initiate a **telnet** session with the Præcis Cntp, this banner will be displayed:

```
*****
*           Welcome to Praecis Cntp telnet console on:  cntp.your.domain
*****
```

Cntp login:

Here you may log in as “cntpuser” with password “Praecis”. When logged in as “cntpuser”, you may check status information and view log files but you will not be able to modify any system settings or view secure files. After correctly entering the password at this prompt,

Password:

the sign on message is shown. It identifies the host system as Præcis Cntp and shows the software part number, version and build date:

```
Praecis Cntp 6010-0003-000 v 1.00 Wed May 16 14:17:44 UTC 2002
Praecis Cntp->
```

This last line is the standard Præcis Cntp shell prompt. The Præcis Cntp uses the **ash** shell, which is a reduced functionality, **bash**-compatible shell. After configuring the

unit, you should change the passwords using the **cntppasswd** command issued from the shell prompt.

To gain *root* access, you must now issue the “super user” command at the shell prompt:

```
Praecis Cntp-> su root
```

You will then be prompted for the password, which is “endrun_1”, and be granted *root* access to the system. To leave “super user” mode, issue the shell command **exit**. Issuing **exit** again will close the **telnet** session.

Using SSH

When establishing a **ssh** connection with your Praecis Cntp, logging in directly as *root* is permitted. When you log in as *root* via a **ssh** session with the Praecis Cntp, this banner will be displayed:

```
*****
*           Welcome to Praecis Cntp SSH console on: cntp.your.domain
*****
root@cntp.your.domain's password:
```

Here you may log in as “root” with password “endrun_1”. After correctly entering the password the sign on message is shown. It identifies the host system as Praecis Cntp and shows the software part number, version and build date:

```
Praecis Cntp 6010-0003-000 v 1.00 Wed Jan 02 14:17:44 UTC 2002
Praecis Cntp->
```

This last line is the standard Praecis Cntp shell prompt. The Praecis Cntp uses the **ash** shell, which is a reduced functionality, **bash**-compatible shell. After configuring the unit, you should change the passwords using the **cntppasswd** command issued from the shell prompt.

Issuing **exit** will close the **ssh** session.

Configuring the Network Time Protocol

Now that the network has been configured and tested, you may configure the operation of the NTP server. By default, the Praecis Cntp is configured to respond to NTP requests from clients that may or may not be using MD5 authentication. If the clients are using MD5 authentication, they must be configured properly with the same MD5 authentication keys as the Praecis Cntp. If you need to modify the factory default Praecis Cntp MD5 keys (recommended) or set up broadcast/multicast operation, then you will need to re-configure the NTP sub-system.

NOTE

If you would like to configure your server for multicast operation, configure it as you would for broadcast operation, with the exception that you must enter this specific NTP multicast address: 224.0.1.1, when you are prompted to enter the broadcast address.

You may perform the configuration from either a **telnet** or **ssh** session or the local RS-232 console. The following is a transcript of the question and answer configuration utility provided by **ntpconfig**. The user entered parameters are underlined:

Praecis Cntp-> ntpconfig

```
*****
*****Network Time Protocol Configuration*****
*****
*
* This script will allow you to configure the ntp.conf and ntp.keys files
* that control Praecis Cntp NTP daemon operation.
*
* You will be able to create new MD5 authentication keys which are stored
* in the ntp.keys file.
*
* You will be able to update the authentication related commands in the
* ntp.conf file.
*
* You will be able to configure the "broadcast" mode of operation, with
* or without authentication. If you supply the multicast address instead
* of your network broadcast address, then you will be able to configure
* the time-to-live of the multicast packets.
*
* The changes you make now will not take effect until you re-boot the
* Praecis Cntp. If you make a mistake, just re-run ntpconfig prior to
* re-booting.
*
* You will now be prompted for the necessary set up parameters.
*
*****
*****
```

---MD5 Keyfile Configuration

Would you like to create a new ntp.keys file? ([y]es, [n]o) y

You will be prompted for a key number (1 - 65534), then the actual key. When you have entered all of the keys that you need, enter zero at the next prompt for a key number.

MD5 keys may contain from 1 to 31 ASCII characters. They may not contain SPACE, TAB, LF, NULL, or # characters!

Enter a key number (1-65534) or 0 to quit: 1

Enter the key (1-31 ASCII characters): EndRun Technologies LLC

Writing key number: 1 and Key: EndRun_Technologies_LLC to ntp.keys

Enter a key number (1-65534) or 0 to quit: 2

Enter the key (1-31 ASCII characters): Praecis Cntp

Writing key number: 2 and Key: Praecis Cntp to ntp.keys

Enter a key number (1-65534) or 0 to quit: 0

---NTP Authentication Configuration

Do you want authentication enabled using some or all of the keys in the ntp.keys file? ([y]es, [n]o) y

You will be prompted for key numbers (1 - 65534), that you want NTP to "trust". The key numbers you enter must exist in your ntp.keys file. If you do not want to use some of the keys in your ntp.keys file, do not enter them here. NTP will treat those keys as "untrusted".

Clients that use any of the "trusted" keys in their NTP polling packets will receive authenticated replies from the Praecis Cntp. When you have entered all of the "trusted keys" that you need, enter zero at the next prompt for a key number.

Enter a trusted key number (1-65534) or 0 to quit: 1

Enter a trusted key number (1-65534) or 0 to quit: 2

Enter a trusted key number (1-65534) or 0 to quit: 0

---NTP Broadcast/Multicast Configuration

Would you like to enable broadcast/multicast server operation? ([y]es, [n]o) y

Set the network broadcast/multicast address for the Praecis Cntp to use. For broadcast mode, this address is the all 1's address on the sub-net.

Example: 111.112.113.255

For multicast operation, it is this specific address: 224.0.1.1

Enter IP address for NTP broadcast/multicast operation (aaa.bbb.ccc.ddd): 224.0.1.1

You have selected multicast operation. Enter the number of hops that are needed for the multicast packets on your network (positive integer): 1

It is highly recommended that authentication be used if you are using NTP in broadcast/multicast mode. Otherwise clients may easily be "spoofed" by a fake NTP server. You can specify an MD5 key number that the Praecis Cntp will use in its broadcast/multicast packets. The clients on your network must be configured to use the same key.

Would you like to specify an MD5 key number to use with broadcast mode? ([y]es, [n]o) y

Enter the MD5 key number to use (1-65534): 2

*
* The Praecis Cntp Network Time Protocol configuration has been updated. *
*
* Please re-boot now for the changes to take effect. *
*

Setting Up NTP Clients on Unix-like Platforms

To configure your Unix-like computer to use your Præcis Cntp, you must have successfully completed the *Basic Installation* procedures in Chapter 2. This manual is not a ‘How-To’ on installing and using NTP; basic approaches to NTP client configuration for operation with the Præcis Cntp will be described. It is expected that you are, or have access to, a capable Unix/Linux system administrator and know more than a little about installing distributions from source code. Installation must be performed by a user with *root* privileges on the system. If you have never used NTP, then you should spend some time reading the on-line documents, especially the Distribution Notes, FAQ and Configuration subject matter, which are available at:

<http://www.ntp.org>

Although all the information is available at the above site, the following are excellent tutorials on setting up NTP and are easier to understand:

<http://www.sun.com/solutions/blueprints/0701/NTP.pdf>

<http://www.sun.com/solutions/blueprints/0801/NTPpt2.pdf>

<http://www.sun.com/solutions/blueprints/0901/NTPpt3.pdf>

Many problems may also be solved by the helpful people who participate in the Internet news group devoted to NTP:

news://your_news_server/comp.protocols.time.ntp

Three methods of using the Præcis Cntp with NTP clients on Unix-like platforms will be described:

Basic This is the simplest, and will operate without MD5 authentication. **NTP beginners should always perform this setup first.**

MD5 This method is trickier only because MD5 keys must be set up and distributed accurately to the NTP clients in a secure way. The Præcis Cntp is factory configured to authenticate its replies to NTP MD5 clients using its default set of keys.

Broadcast/Multicast This method simplifies configuration of the clients on large networks since specific server addresses need not be configured in each client's */etc/ntp.conf* file. It can be configured either with or without MD5 authentication. However, it is highly recommended that authentication be configured when using broadcast/multicast mode due to the relative ease with which a fake NTP server can take over the clock setting of the broadcast/multicast clients on the network.

Basic NTP Client Setup

Basic setup is relatively simple, if:

- You have been able to successfully communicate with the Præcis Cntp on your network.
- You have installed NTP on your client computer.

Configure NTP

You must edit the *ntp.conf* file which **ntpd**, the NTP daemon, looks for by default in the */etc* directory. Add this line to the *ntp.conf* file:

```
server 192.168.1.245
```

This line tells **ntpd** to use the NTP server at address 192.168.1.245 in addition to any other servers which might also be configured in the client's *ntp.conf* file.

Re-start **ntpd** to have it begin using the Præcis Cntp server. Use the NTP utility **ntpq** to check that **ntpd** is able to communicate with the Præcis Cntp. After issuing the command

```
ntpq
```

you will see the **ntpq** command prompt:

```
ntpq>
```

Use the command

peers

to display the NTP peers which your computer is using. One of them should be the Præcis Cntp server which you have just configured. You should verify that it is being ‘reached’. (You may have to continue issuing the peers command for a minute or two before you will see the ‘reach’ count increment.) If you have other peers configured, verify that the offset information for the Præcis Cntp server peer and your other peers is in agreement to within a few milliseconds, assuming that the other peers are synchronized to that level of accuracy.

It may also be useful to start the NTP daemon in ‘debug’ mode (**ntpd -d**) to confirm successful configuration. Refer to the NTP documentation for detailed usage of these debug utilities.

MD5 Authenticated NTP Client Setup

MD5 authenticated setup is relatively simple, if:

- You have been able to successfully communicate with the Præcis Cntp on your network.
- Your Præcis Cntp has been configured to perform authentication either by factory default, or by running the **ntpconfig** shell script. The example Præcis Cntp authentication configuration shown in Chapter 2 – *Configuring the Network Time Protocol* will be assumed in the example configuration commands shown here.
- You have installed NTP on your client computer.
- You have successfully performed the *Basic NTP Client Setup* on your client computer.

Create the *ntp.keys* file

You must create a file named *ntp.keys* in the */etc* directory. It must be a copy of the one residing in the */etc* directory of your Præcis Cntp. You can **telnet** into your Præcis Cntp and start an **ftp** session with your client computer to send the Præcis Cntp’s */etc/ntp.keys* file to your client computer, use the secure copy utility **scp**, or you can just use a text editor on your client computer to create an equivalent file.

IMPORTANT

Handling of the `/etc/ntp.keys` file is the weak link in the MD5 authentication scheme. It is very important that it is owned by `root` and not readable by anyone other than `root`.

After transferring the file by `ftp`, and placing it in the `/etc` directory on the client computer, issue these two commands at the shell prompt:

```
chown root.root /etc/ntp.keys
chmod 600 /etc/ntp.keys
```

Configure NTP

You must edit the `ntp.conf` file which `ntpd`, the NTP daemon, looks for by default in the `/etc` directory. Assuming that you have created two trusted keys as shown in the example in the previous chapter, add these lines to the end of the `ntp.conf` file:

```
keys /etc/ntp.keys
trustedkey 1 2
```

Modify the line added previously in *Basic NTP Client Setup* so that authentication will be used with the Præcis Cntp server using one of the trusted keys, in this case key # 1:

```
server 192.168.1.245 key 1
```

Re-start `ntpd` to have it begin using the Præcis Cntp server with MD5 authentication. Use the NTP utility `ntpq` to check that `ntpd` is able to communicate with the Præcis Cntp. After issuing the command

```
ntpq
```

you will see the `ntpq` command prompt:

```
ntpq>
```

Use the command

```
peers
```

to display the NTP peers which your computer is using. One of them should be the Præcis Cntp server which you have just configured. You should verify that it is being 'reached'. (You may have to continue issuing the `peers` command for a minute or two before you will see the 'reach' count increment.)

You can verify that authentication is being used by issuing the command

```
associations
```

to display the characteristics of the client server associations. In the “auth” column of the display, you should see “OK” for the row corresponding to the Præcis Cntp server. If you see “bad”, you should wait a few minutes to be sure that there is a problem since “bad” is the initial state of this setting. If the “bad” indication persists then you must check your configuration for errors. Typically this is due to a typing error in creating the `/etc/ntp.keys` file on the client that causes a mismatch between the keys being used by the server and client. (If you transfer the file by **ftp** or **scp**, this shouldn't be a problem.) It is also possible to have a typing error in the `/etc/ntp.conf` file that causes the needed key to not be included in the “trustedkey” list.

Broadcast/Multicast NTP Client Setup

Broadcast/multicast client setup is relatively simple, if:

- You have been able to successfully communicate with the Præcis Cntp on your network.
- Your Præcis Cntp has been configured to perform broadcasts or multicasts by running the **ntpconfig** shell script. (This is not the factory default configuration, so be sure to run **ntpconfig**.) If you are going to use MD5 authentication, your Præcis Cntp must have been configured to operate with authentication in the broadcast/multicast mode, and you must know which of the trusted keys it is using for broadcast/multicast operation. The example Præcis Cntp configuration shown in Chapter 2 – *Configuring the Network Time Protocol* will be assumed in the example configuration commands shown here.
- You have installed NTP on your client computer.
- You have successfully performed the *MD5 Authenticated NTP Client Setup* on your client computer, if you plan to use MD5 authentication.

Configure NTP

You must edit the `ntp.conf` file which **ntpd**, the NTP daemon, looks for by default in the `/etc` directory. Assuming that your Præcis Cntp server has been configured to use key 2 for broadcast authentication as shown in the example in Chapter 2, make sure that key 2 is included in the **trustedkey** line, and add this line to the end of the `ntp.conf` file:

```
broadcastclient
```

If you are not using MD5 authentication, you would add these lines:

```
disable auth
broadcastclient
```

If you are using multicast instead of broadcast mode, you would replace the **broadcast-**

`client` keyword with the `multicastclient` keyword. You may remove the line added previously in *Basic NTP Client Setup*:

```
server 192.168.1.245
```


Setting Up NTP Clients on Windows NT 4.0/2000

To configure your Windows NT 4.0/2000 computer to use your Præcis Cntp, you must have successfully completed the *Basic Installation* procedures in Chapter 2. This manual is not a 'How-To' on installing and using NTP; basic approaches to NTP configuration for operation with the Præcis Cntp will be described here. Installation must be performed by a user with administrative privileges on the system. If you have never used NTP, then you should spend some time reading the on-line documents at:

<http://www.ntp.org>

Although all the information is available at the above site, the following are excellent tutorials on setting up NTP and are easier to understand:

<http://www.sun.com/solutions/blueprints/0701/NTP.pdf>

<http://www.sun.com/solutions/blueprints/0801/NTPpt2.pdf>

<http://www.sun.com/solutions/blueprints/0901/NTPpt3.pdf>

Many problems may also be solved by the helpful people who participate in the Internet news group devoted to NTP:

news://your_news_server/comp.protocols.time.ntp

Three methods of using the Præcis Cntp with NTP clients on Window NT 4.0 platforms will be described:

Basic This is the simplest, and will operate without MD5 authentication. **NTP beginners should always perform this setup first.**

MD5 This method is trickier only because MD5 keys must be set up and distributed accurately to the NTP clients in a secure way. The Præcis Cntp is factory configured to authenticate its replies to NTP MD5 clients using its default set of keys.

Broadcast/Multicast This method simplifies configuration of the clients on large networks since specific server addresses need not be configured in each client's `\winnt\system32\drivers\etc\ntp.conf` file. It can be configured either with or without MD5 authentication. However, it is highly recommended that authentication be configured when using broadcast/multicast mode due to the relative ease with which a fake NTP server can take over the clock setting of the broadcast/multicast clients on the network.

Basic NTP Client Setup

Basic setup is relatively simple, if:

- You have been able to successfully communicate with the Præcis Cntp on your network.
- You have installed NTP on your client computer.

Configure NTP

You must edit the `ntp.conf` file which `ntpd.exe`, the NTP daemon, looks for by default in the the `\winnt\system32\drivers\etc` directory of the boot partition. If your NTP installation placed this file in a different place, you must find it and edit it. Add this line to the `ntp.conf` file:

```
server 192.168.1.245
```

This line tells `ntpd.exe` to use the NTP server at address 192.168.1.245 in addition to any other servers which might also be configured in the `ntp.conf` file.

Re-start `ntpd.exe` to have it begin using the Præcis Cntp server. By default, the NTP installation program installs `ntpd.exe` as a service called Network Time Protocol, and starts it. You must use the Services utility in Control Panel to stop the Network Time Protocol service and then re-start it.

Use the NTP utility `ntpq.exe` to check that `ntpd.exe` is able to communicate with the Præcis Cntp. By default it is installed in the `\Program Files\Network Time Protocol` sub-directory of your Windows NT partition. From a console window, after issuing the command

ntpq

you will see the **ntpq** command prompt:

ntpq>

Use the command

peers

to display the NTP peers which your computer is using. One of them should be the Præcis Cntp server which you have just configured. You should verify that it is being 'reached'. (You may have to continue issuing the **peers** command for a minute or two before you will see the 'reach' count increment.) If you have other peers configured, verify that the offset information for the Præcis Cntp server peer and your other peers is in agreement to within a few milliseconds, assuming that the other peers are synchronized to that level of accuracy.

It may also be useful to start the NTP daemon in 'debug' mode (**ntpd -d**) to confirm successful configuration. The debug version of the NTP daemon is located in the *debug* sub-directory of your NTP directory. Refer to the NTP documentation for detailed usage of these debug utilities.

MD5 Authenticated NTP Client Setup

MD5 authenticated setup is relatively simple, if:

- You have been able to successfully communicate with the Præcis Cntp on your network.
- Your Præcis Cntp has been configured to perform authentication either by factory default, or by running the **ntpconfig** shell script. The example Præcis Cntp authentication configuration shown in Chapter 2 – *Configuring the Network Time Protocol* will be assumed in the example configuration commands shown here.
- You have installed NTP on your client computer.
- You have successfully performed the *Basic NTP Client Setup* on your client computer.

Create the *ntp.keys* file

You must create a file named *ntp.keys* in the `\winnt\system32\drivers\etc` directory. It must be a copy of the one residing in the */etc* directory of your Præcis Cntp. You can **telnet** into your Præcis Cntp and start an **ftp** session with your client computer to send the Præcis Cntp */etc/ntp.keys* file to your client computer, or use the secure copy utility **scp**, or use a text editor to create the equivalent file. Although you should first test your

setup using the factory default `/etc/ntp.keys` file in your Præcis Cntp server, you should create your own keys after you understand the process and have your clients operating correctly with the default file.

IMPORTANT

Handling of the `/etc/ntp.keys` file is the weak link in the MD5 authentication scheme. It is very important that it is owned by “administrator” and not readable by anyone other than “administrator”.

After transferring the file, make sure that its security properties are set such that it is readable only by the “administrator”.

Configure NTP

You must edit the `ntp.conf` file which `ntpd.exe`, the NTP daemon, looks for by default in the the `\winnt\system32\drivers\etc` directory. If your NTP installation placed this file in a different place, you must find it and edit it. Add these lines to the end of the `ntp.conf` file:

```
keys \winnt\system32\drivers\etc\ntp.keys
trustedkey 1 2
```

Modify the line added previously in *Basic NTP Client Setup* so that authentication will be used with the Præcis Cntp server using one of the trusted keys, in this case key # 1:

```
server 192.168.1.245 key 1
```

Re-start `ntpd.exe` to have it begin using the Præcis Cntp server with MD5 authentication. By default, the NTP installation program installs `ntpd.exe` as a service called Network Time Protocol, and starts it. You must use the Services utility in Control Panel to stop the Network Time Protocol service and then re-start it.

Use the NTP utility `ntpq.exe` to check that `ntpd.exe` is able to communicate with the Præcis Cntp. By default it is installed in the `\Program Files\Network Time Protocol` sub-directory of your Windows NT partition. From a console window, after issuing the command

```
ntpq
```

you will see the `ntpq` command prompt:

```
ntpq>
```

Use the command

```
peers
```

to display the NTP peers which your computer is using. One of them should be the Præcis Cntp server which you have just configured. You should verify that it is being ‘reached’. (You may have to continue issuing the peers command for a minute or two before you will see the ‘reach’ count increment.)

You can verify that authentication is being used by issuing the command

associations

to display the characteristics of the client server associations. In the “auth” column of the display, you should see “OK” for the row corresponding to the Præcis Cntp server. If you see “bad”, you should wait a few minutes to be sure that there is a problem since “bad” is the initial state of this setting. If the “bad” indication persists then you must check your configuration for errors. Typically this is due to a typing error in creating the `\winnt\system32\drivers\etc\ntp.keys` file on the client that causes a mismatch between the keys being used by the server and client. (If you transfer the file by **ftp** or **scp**, this shouldn’t be a problem.) It is also possible to have a typing error in the `\winnt\system32\drivers\etc\ntp.conf` file that causes the needed key to not be included in the “trustedkey” list.

Broadcast/Multicast NTP Client Setup

Broadcast/multicast client setup is relatively simple, if:

- You have been able to successfully communicate with the Præcis Cntp on your network.
- Your Præcis Cntp has been configured to perform broadcasts or multicasts by running the **ntpconfig** shell script. (This is not the factory default configuration, so be sure to run **ntpconfig**.) If you are going to use MD5 authentication, your Præcis Cntp must have been configured to operate with authentication in the broadcast/multicast mode, and you must know which of the trusted keys it is using for broadcast/multicast operation. The example Præcis Cntp configuration shown in Chapter 2 – *Configuring the Network Time Protocol* will be assumed in the example configuration commands shown here.
- You have installed NTP on your client computer.
- You have successfully performed the *MD5 Authenticated NTP Client Setup* on your client computer, if you plan to use MD5 authentication.

Configure NTP

You must edit the *ntp.conf* file which **ntpd**, the NTP daemon, looks for by default in the the `\winnt\system32\drivers\etc` directory. Assuming that your Præcis Cntp server has been configured to use key 2 for broadcast authentication as shown in the example in Chapter 2, make sure that key 2 is included in the **trustedkey** line, and add this line to the end of the *ntp.conf* file:

```
broadcastclient
```

If you are not using MD5 authentication, you would add these lines:

```
disable auth
broadcastclient
```

If you are using multicast instead of broadcast mode, you would replace the **broadcastclient** keyword with the **multicastclient** keyword. You may remove the line added previously in *Basic NTP Client Setup*:

```
server 192.168.1.245
```

or the authenticated version added in *MD5 Authenticated NTP Client Setup*:

```
server 192.168.1.245 key 1
```

Re-start **ntpd.exe** to have it begin using the Præcis Cntp as a broadcast or multicast server. By default, the NTP installation program installs **ntpd.exe** as a service called Network Time Protocol, and starts it. You must use the Services utility in Control Panel to stop the Network Time Protocol service and then re-start it.

Use the NTP utility **ntpq.exe** to check that **ntpd.exe** is able to communicate with the Præcis Cntp. By default it is installed in the `\Program Files\Network Time Protocol` sub-directory of your Windows NT partition. After issuing the command

```
ntpq
```

you will see the **ntpq** command prompt:

```
ntpq>
```

Use the command

```
peers
```

to display the NTP peers which your computer is using. One of them should be the Præcis Cntp server which you have just configured. You should verify that it is being 'reached'. (You may have to continue issuing the **peers** command for a minute or two before you will see the 'reach' count increment.)

If you are using authentication, you can verify that authentication is being used by issuing the command

associations

to display the characteristics of the client server associations. In the “auth” column of the display, you should see “OK” for the row corresponding to the Præcis Cntp server. If you see “bad”, you should wait a few minutes to be sure that there is a problem since “bad” is the initial state of this setting. If the “bad” indication persists then you must check your configuration for errors. Typically this is due to a typing error in creating the */etc/ntp.keys* file on the client that causes a mismatch between the keys being used by the server and client. (If you transfer the file by **ftp** or **scp**, this shouldn't be a problem.) It is also possible to have a typing error in the */etc/ntp.conf* file that causes the needed key to not be included in the “trustedkey” list.



Control and Status Commands

This appendix describes the Præcis Cntp control and status commands. In addition to a subset of the standard Linux shell commands/utilities, the Præcis Cntp supports several application-specific commands for performing initialization/setup and for monitoring the performance and status of the NTP and CDMA sub-systems. The standard Linux commands are not documented here. A wealth of information is available from a variety of sources on those. Only the Præcis Cntp specific commands will be described here. The serial I/O port physical and electrical characteristics are defined as well.

General Linux Shell Operation

The command shell used by the Præcis Cntp is a **bash** equivalent that is known as **ash**. **ash** offers good compatibility in running shell scripts written for **bash**, but lacks some of the niceties of **bash**. In particular, it lacks command line editing. All commands and file names are case sensitive, which is standard for Unix-like operating systems. If you are unfamiliar with Unix-like operating systems, and you would like to be able to more closely monitor or optimize the performance of your Præcis Cntp you should consult either the web

www.linuxdoc.org

or good Linux reference books like:

Linux in a Nutshell, Seiver, O'Reilly & Associates, 1999.

Running Linux, Welsh, Dalheimer & Kaufman, O'Reilly & Associates, 1999

to learn the ins and out of the Linux command console.

Available User Commands

COMMAND	FUNCTION
accessconfig	Interactive shell script that guides the user in configuring telnet , ssh and snmpd access to the Præcis Cntp that is limited to specific hosts. The resulting <i>/etc/hosts.allow</i> and <i>/etc/hosts.deny</i> files are saved to the non-volatile FLASH disk. Factory default configuration allows access by all hosts.
cdmaleapconfig	Guides the user in configuring the way in which UTC leap seconds are handled: either AUTOMATICALLY via CDMA basestation transmissions or by USER entered current and future leap second parameters.
cdmaleapmode	Prints the current CDMA leap second mode of operation, either AUTO or USER. If USER, prints the current and future leap second values.
cdmastat	Prints the CDMA sub-system status information to the console.
cdmaversion	Prints the CDMA firmware and FPGA version information to the console.
cntpenableupgrade	Enables a firmware upgrade by mounting the FLASH disk partitions that hold compressed root file system images.
cntphwaddr	Prints the ethernet hardware address, if the ethernet has been configured.
cntposctype	Prints the installed oscillator type, which is one of: TCXO, DIP-OCXO, MS-OCXO, HS-OCXO or Rubidium.
cntpasswd	Allows the <i>root</i> user to change the password for the two configured users on the Præcis Cntp: <i>cntpuser</i> and <i>root</i> . This script calls the standard Linux passwd binary and then saves the resulting <i>/etc/shadow</i> file to the non-volatile FLASH disk.
cntprootfs	Prints the current root file system image, either 0 (factory default) or 1 (field upgrade) which is running in the Præcis Cntp to the console.
cntpstat	Parses the output of ntpq -c peers to obtain the system peer status of the NTP CDMA reference clock. It also retrieves the current reference clock polling status data and prints it to the console.

cntptimemode	Prints the time mode settings in effect for any optional timecode output or optional front panel vacuum fluorescent display.
cntptimemodeconfig	Interactive shell script that guides the user in configuring the time mode settings for any optional timecode output or front panel vacuum fluorescent display. Allows setting to the LOCAL_AUTO, LOCAL_MANUAL, GPS or UTC timescale and if LOCAL_MANUAL, the setting of the offset to UTC and the Daylight Savings Time (DST) start and stop date/time parameters.
cntpversion	Prints the Præcis Cntp application software version information to the console.
ntpconfig	Interactive shell script that guides the user in configuring the Præcis Cntp NTP sub-system. Allows configuration of MD5 authentication and broadcast/multicast mode. All parameters are retained in non-volatile FLASH disk storage.
updatelilo	Shell script that must be run to update the Linux Loader (LILO) so that it will boot a new root file system image. cntpenableupgrade must have been previously executed in order to run this command.

Detailed Command Descriptions

accessconfig

This command starts an interactive shell script that will allow the root user to configure limitation of **telnet**, **ssh** and **snmp** access to the Præcis Cntp. By default, the unit is configured to allow access by all users. If you need to limit **telnet**, **ssh** or **snmp** access, e.g. for security reasons, you must run this script as *root* from either the RS-232 serial I/O port or from a **telnet** or **ssh** session.

This script modifies these files: */etc/hosts.allow* and */etc/hosts.deny*. These are non-volitely stored in the FLASH disk */boot/etc* directory. You must re-boot the Præcis Cntp after running this script for the changes to take effect.

Usage:

Set: **accessconfig**

Præcis Cntp response: *interactive shell script is started*

cdmaleapconfig

This command starts an interactive shell script that will guide the root user in configuring the way that UTC leap seconds are applied. Although the CDMA system provides an automatic mechanism for disseminating UTC leap second information to the mobile units, it may not be precise enough for many Præcis Cntp users. If you need your Præcis Cntp to precisely handle any UTC leap second insertions at midnight on June 30th or January 31st (the times that leap seconds are inserted), then you should consider configuring your Præcis Cntp to operate in the USER CDMA leap second mode.

In the USER CDMA leap second mode, you must provide the current and future leap second values. These are posted by the International Earth Rotation Service (www.iers.org) approximately six months in advance of their insertion. The interactive script is very detailed in explaining how these values are obtained and used.

Usage:

Query: `cdmaleapconfig`
 Præcis Cntp response: *interactive shell script is started*

cdmaleapmode

This command displays the CDMA leap mode of operation currently configured. There are two modes: AUTO and USER. If the mode is USER, then the values of the configured current and future leap seconds are also displayed.

Usage:

Query: `cdmaleapmode`
 Præcis Cntp response: **CDMA Leap Second Mode is AUTO**
CDMA Leap Second Mode is USER: Current LS = 13, Future LS = 13

cdmastat

This command allows the user to query the status of the CDMA timing sub-system. During normal operation, the NTP daemon polls the CDMA timing sub-system every 16 seconds. The results of this poll are used to steer the system clock and are saved to a log file. This command parses and formats the data contained therein and prints this fixed-length string having these fields:

```
LKSTAT TFOM = ? YEAR DOY HH:MM:SS.ssssssss LS S C PNO AGC VCDAC SN.R F.ERR FLT5
```

Where:

- LKSTAT is the tracking status of the engine, either LOCKED or NOTLKD.
- TFOM = ? shows the Time Figure of Merit (TFOM) of the CDMA engine's internal timebase. ? may take values ranging from 6 to 9:
 - 6 time error is < 100 us
 - 7 time error is < 1 ms

- 8 time error is < 10 ms
- 9 time error is > 10 ms, unsynchronized state if never been locked to CDMA.

Refer to *Time Figure of Merit* at the end of this section for a detailed description of the meaning of this number.

YEAR	is the year of the UTC timestamp of the most recent NTP polling request received by the CDMA engine from the NTP reference clock driver.
DOY	is the day-of-year of the UTC timestamp of most recent NTP polling request received by the CDMA engine from the NTP reference clock driver.
HH:MM:SS.ssssssss	is the hour, minute, second.subsecond UTC timestamp of the most recent NTP polling request received by the CDMA engine from the NTP daemon reference clock driver.
LS	is the current number of leap seconds difference between the UTC and GPS timescales (13 at the time of this writing).
S	is the Signal Processor State, one of 0 (Acquiring), 1 (Signal Detected), 2 (Code Locking), 4 (Carrier Locking), 8 (Locked).
C	is the CDMA frequency channel being used, one of 0 (Primary A), 1 (Primary B), 2 (Secondary A), 3 (Secondary B).
PNO	is the base station PseudoNoise Offset, 0 to 511 in units of 64 PseudoNoise code chips.
AGC	is the Automatic Gain Control DAC byte, 0 to 255 with larger numbers implying higher RF gain. Typical range is 150 to 220.
VCDAC	is the TCXO Voltage Control DAC word, 0 to 65535 with larger numbers implying higher TCXO frequency. Typical range is 20000 to 38000.
SN.R	is the carrier Signal to Noise Ratio, 0.00 to 99.9, measured in the Sync Channel symbol rate bandwidth. Typical range is 2.5 to 11.0.
FERR	is the Sync Channel Frame Error Rate, 0.000 to 1.000, with a higher number implying more Cyclical Redundancy Check failures when

processing the Sync Channel message frames. Higher numbers will correlate with lower Signal to Noise Ratios.

FLTS is the fault status, which displays the current summary status of the CDMA timing sub-system. The summary status is contained in sixteen bits which are displayed in four hexadecimal characters. Assertion of any of these bits will also be indicated by illumination of the red LED. Each bit of each character indicates the status of a sub-system component:

Hex Character	Bit 3	Bit 2	Bit 1	Bit 0
0	FLASH Write Fault	FPGA Config Fault	No Signal Time-Out	DAC Control Over-Range
1	Not Used	No Polling Events	Local Oscillator Failure	Local Oscillator PLL Fault
2	Not Used	Not Used	Not Used	Not Used
3	Not Used	Not Used	Not Used	Not Used

DAC Control Over-Range This bit indicates that the electronic frequency control DAC for the oscillator has reached either the high (55000) or low (10000) limit while locked to the CDMA signal. Unless the unit is being subjected to out-of-specification environmental conditions, this would indicate that the oscillator frequency has drifted near to the end of life region. This should normally only occur after about ten years of operation. The unit will continue to function until the oscillator frequency finally reaches one of the actual DAC endpoints. The unit should be returned to the factory for oscillator replacement at the customer's convenience.

No Signal Time-Out This bit indicates that the unit has not been able to acquire a CDMA signal for one hour while the Time Figure of Merit has been 9, the unsynchronized condition. This could be due to a variety of reasons. If there are no other faults that could explain the inability to receive a signal, then there could be a base station outage or antenna blockage. If the condition persists indefinitely, the unit may need to be returned to the factory for repair.

FPGA Config Fault	This bit indicates that the microprocessor was unable to configure the FPGA. This would be a fatal fault and the unit should be returned to the factory .
FLASH Write Fault	This bit indicates that the microprocessor was unable to verify a write to the FLASH non-volatile parameter storage area. This should not ever occur under normal operation. This fault would cause erratic operation at the next power cycling since important parameters could be corrupt. The unit should be returned to the factory for repair.
Local Oscillator PLL Fault	This bit indicates that the Local Oscillator Phase Locked Loop (PLL) synthesizer is unlocked. This condition should not normally occur unless the unit is subjected to out-of-specification environmental conditions. Otherwise, this would be a fatal fault and the unit should be returned to the factory for repair.
Local Oscillator Failure	This bit indicates that the Local Oscillator Phase Locked Loop (PLL) synthesizer has failed. This condition should not normally occur unless the unit is subjected to out-of-specification environmental conditions. This is a fatal fault and the unit should be returned to the factory for repair.
No Polling Events	This bit indicates that the CDMA timing sub-system is not receiving polling request from the NTP sub-system. This could be due to a hardware or software failure. If the condition persists after cycling the power to the unit, this is a fatal fault and the unit should be returned to the factory for repair.

The example response indicates that there has been a period without tracking a CDMA signal that exceeded the time-out period, that there was a FLASH Write Fault and that there is a Local Oscillator PLL fault.

Usage:

Query: `cdmastat`

Præcis Cntp response:

`LOCKED TFOM = 6 2001 092 04:48:56.347916732 13 8 1 132 179 28605 8.6 0.000 001A`

cdmaversion

This command displays the firmware and hardware versions of the CDMA sub-system.

Usage:

Query: `cdmaversion`
 Præcis Cntp response: `F/W 2.00 FPGA 06`

cntpenableupgrade

This command mounts the two FLASH disk root file system partitions as part of the firmware upgrade procedure. Refer to Appendix B – *Upgrading the Firmware* for detailed instructions for performing the upgrade procedure.

Usage:

Set: `cntpenableupgrade`
 Præcis Cntp response: `Mounting root file system partitions.`

cntphwaddr

This command displays the ethernet hardware address, if the IP network is properly configured. Otherwise it returns nothing.

Usage:

Query: `cntphwaddr`
 Præcis Cntp response: `00:D0:C9:25:78:59`

cntposctype

This command displays the installed oscillator type. It is one of TCXO, DIP-OCXO, MS-OCXO, HS-OCXO or Rubidium. The standard oscillator is the TCXO.

Usage:

Query: `cntposctype`
 Præcis Cntp response: `Installed Oscillator is TCXO`

cntppasswd

This command allows the root user to change the passwords of the two configured users on the system: *root* and *cntpuser*. Arguments passed to **cntppasswd** on the command line are passed verbatim to the real **passwd** binary program. When **passwd** returns, the resulting modified */etc/shadow* file is copied to the non-volatile */boot/etc* directory.

Usage:

Set: `cntppasswd cntpuser`
 Præcis Cntp response: `The passwd interactive utility is started`

cntproofs

This command displays the currently booted root file system image. It can be either PraecisCntp_0 (factory image) or PraecisCntp_1 (field upgrade image). Refer to Appendix B – *Upgrading the Firmware* for detailed instructions for performing the upgrade procedure.

Usage:

Query: `cntproofs`
 Praecis Cntp response: `BOOT_IMAGE=PraecisCntp_1`

cntpstat

This command allows the user to query the status of the NTP sub-system. It retrieves information from the NTP distribution `ntpq` binary using the `peers` command to determine the current synchronization status of the NTP sub-system. It then retrieves the last line in the logfile `/var/log/praecis0.monitor` controlled by the NTP daemon reference clock driver that communicates with the CDMA timing sub-system. This logfile is updated every 16 seconds under normal operation. It parses and formats the data contained therein and prints this fixed-length (generally, grossly unsynchronized states could cause the floating offset field to overflow momentarily) string having these fields:

```
LKSTAT TO CDMA, Offset = +S.ssssss, TFOM = ? @ YEAR DOY HH:MM:SS.ssssssss LS
```

Where:

- LKSTAT is the system peer status of the NTP daemon relative to the CDMA sub-system engine, either LOCKED or NOTLKD. NOTLKD can imply several things: the system has just started, there is a fault in the CDMA sub-system which has caused NTP to either be unable to obtain timing information from the CDMA sub-system or to reject the timing information that it is obtaining from it
- +S.ssssss is the offset in seconds between the NTP system clock and the CDMA sub-system clock. Positive implies that the system clock is ahead of the CDMA sub-system clock.
- TFOM = ? shows the Time Figure of Merit (TFOM) of the CDMA engine's internal timebase. ? may take values ranging from 6 to 9:
 - 6 time error is < 100 us
 - 7 time error is < 1 ms
 - 8 time error is < 10 ms
 - 9 time error is > 10 ms, unsynchronized state if never been locked to CDMA.

Refer to *Time Figure of Merit* at the end of this section for a detailed description of the meaning of this number.

YEAR is the year of the UTC timestamp of most recent NTP polling request received by the CDMA engine from the NTP reference clock driver.

DOY is the day-of-year of the UTC timestamp of most recent NTP polling request received by the CDMA engine from the NTP reference clock driver.

HH:MM:SS.ssssssss

is the hour, minute, second.subsecond UTC timestamp of the most recent NTP polling request received by by the CDMA engine from the NTP daemon reference clock driver.

LS is the current number of leap seconds difference between the UTC and GPS timescales (13 at the time of this writing).

Usage:

Query: `cntpstat`
 Précis Cntp response:

```
LOCKED TO CDMA, Offset = +0.000024, TFOM = 6 @ 2001 092 06:03:10.904312858 13
```

cntptimemode

This command displays the current time mode settings for any optional timecode outputs or the front panel vacuum fluorescent display. The displayed Local Time Offset from UTC is valid in either of the two LOCAL modes, but the Daylight Savings Time (DST) Start/Stop parameters are only valid in the LOCAL_MANUAL mode. A positive Local Time Offset implies a longitude east of the Greenwich meridian and that local time is ahead of UTC.

There are two LOCAL time modes: LOCAL_AUTO and LOCAL_MANUAL. In the LOCAL_AUTO mode, the local offset from UTC is determined from the CDMA base station transmissions. For more precise and deterministic behavior at the DST change-over times, you should configure your unit for LOCAL_MANUAL operation and set up the local offset and the DST start and stop times using `cntptimemodeconfig`.

Usage:

Query: `cntptimemode`
 Précis Cntp response:

```
Time Mode = UTC
Local Time Offset from UTC = -16 (half hours)
DST Start Month = Apr Sunday = 1st Hour = 02
DST Stop Month = Oct Sunday = Last Hour = 02
```

cntptimemodeconfig

This command starts an interactive shell script that will allow the user to configure the time mode of operation of any optional timecode outputs or front panel vacuum fluorescent display of the Præcis Cntp. *These settings have no effect on the operation of the NTP daemon or the underlying Linux operating system time. These ALWAYS operate in UTC.*

By default, the unit is configured to operate in LOCAL_AUTO mode. If you need to modify this operation, you must run this script as *root*. Settings made using this command are non-volatile.

Usage:

Set: `cntptimemodeconfig`
 Præcis Cntp response: *interactive shell script is started*

cntpversion

This command displays the firmware version and build date of the Præcis Cntp.

Usage:

Query: `cntpversion`
 Præcis Cntp response:

Præcis Cntp 6010-0002-000 v 1.00 Wed Jan 16 22:38:21 UTC 2002

inetdconfig

This command starts an interactive shell script that will allow the user to configure the list of protocol servers which are started by the **inetd** server daemon running in the Præcis Cntp. Four protocol servers may be configured: TIME, DAYTIME, TELNET and SSH. By default, the unit is configured to start all of these protocol servers. If you need to disable start-up of some or all of these, e.g. for security reasons, you must run this script as *root* from either the RS-232 serial I/O port or from a **telnet** or **ssh** session.

This script modifies the `/etc/inetd.conf` file, which is non-volatilely stored in the FLASH disk `/boot/etc` directory. You must re-boot the Præcis Cntp after running this script for the changes to take effect.

Usage:

Set: `inetdconfig`
 Præcis Cntp response: *interactive shell script is started*

netconfig

This command starts an interactive shell script that will allow the user to configure the IP network sub-system of the Præcis Cntp. By default, the unit is configured to configure itself using the Dynamic Host Configuration Protocol (DHCP). If you need to set up static IP configuration, you must run this script as *root* from the RS-232 serial I/O

port during the installation process. Refer to Chapter 2 – *Using netconfig to Set Up Your IP* for details on the use of the command.

This script creates or modifies these files: */etc/HOSTNAME*, */etc/hosts*, */etc/networks*, */etc/resolv.conf* and */etc/rc.d/rc.inet1*. All of these are non-volatilely stored in the FLASH disk */boot/etc* directory. You must re-boot the Præcis Cntp after running this script for the changes to take effect.

Usage:

Set: `netconfig`
 Præcis Cntp response: *interactive shell script is started*

ntpconfig

This command starts an interactive shell script that will allow the user to configure the NTP sub-system of the Præcis Cntp. By default, the unit is configured to authenticate its replies to clients using its default MD5 keys in the */etc/ntp.keys* file. If you need to create your own MD5 keys (recommended) or set up broadcast/multicast operation, you must run this script as *root*. Refer to Chapter 2 - *Configuring the Network Time Protocol* for details on the use of this command.

The two files that are modified are */etc/ntp.keys* and */etc/ntp.conf*. Both of these are non-volatilely stored in the FLASH disk */boot/etc* directory. You must re-boot the Præcis Cntp after running this script for the changes to take effect.

Usage:

Set: `ntpconfig`
 Præcis Cntp response: *interactive shell script is started*

updatelilo

This command allows the user to update the configuration of the Linux Loader (LILO) after a new root file system image has been uploaded to the upgrade root file system partition, */rootfs_1* of the Præcis Cntp FLASH disk. Refer to Appendix B – *Upgrading the Firmware* for detailed instructions for performing the upgrade procedure. Two arguments are accepted, first either 0 or 1 to tell LILO which root file system image should be made the default, second the file name of the new compressed root file system image. If no arguments or any value other than 1 is given for the first argument, the default root file system is set to *PræcisCntp_0*. If the first argument is 1, then the second argument is read and LILO is re-configured to make the default root file system *PræcisCntp_1*.

Upon completion, the root file system partitions are unmounted.

Usage:

Set: `/boot/updatelilo 1 rootfs1.01.gz`
 Præcis Cntp response:

```
Added PraecisCntp_0  
Added PraecisCntp_1 *
```

Unmounting root file system partitions now. Run Cntpenableupgrade again to remount them, should you need to re-run updatelilo.

The trailing asterisk '*' character indicates that the default root file system is set to PraecisCntp_1.

Time Figure of Merit

The time-of-day fields printed by the Præcis Cntp `cdmastat` and `cntpstat` commands contain a character that indicates the level of accuracy that should be included in the interpretation of the time-of-day contained in the message. This character is referred to as the 'Time Figure of Merit' (TFOM).

In all cases, the Præcis Cntp reports this value as accurately as possible, even during periods of CDMA signal outage where the Præcis Cntp is unable to directly measure the relationship of its timing outputs to UTC. During these CDMA outage periods, assuming that the Præcis Cntp had been synchronized prior to the outage, the Præcis Cntp extrapolates the expected drift of the Præcis Cntp timing signals based on its knowledge of the characteristics of the internal Temperature Compensated Crystal Oscillator (TCXO), Oven Controlled Crystal Oscillator (OCXO) or Rubidium oscillator. The extrapolated TFOM is based on a conservative estimate of the performance of the oscillator and should be considered 'worst case' for a typical benign ambient temperature environment.

Due to this extrapolation behavior, after initial synchronization, brief periods without CDMA signal reception will not induce an immediate alarm condition. If the condition persists for long enough periods, you should see the TFOM character change to indicate a gradually deteriorating accuracy of the timing outputs. If the signal loss condition persists longer, then the final, unsynchronized state will eventually be reached. If the Præcis Cntp is unable to achieve re-synchronization within one hour after reaching this state, the red LED will illuminate. The fault status field returned in either of the `cdmastat` or `cntpstat` commands will have the appropriate bit set to indicate a loss-of-signal time-out condition.

If the CDMA sub-system reaches the unsynchronized TFOM state, the NTP daemon will cease to use the timing information returned by the CDMA sub-system in its polling event timestamps. At this point, the NTP daemon will report in its replies to network NTP clients that are receiving synchronization from the Præcis Cntp that it is running at stratum 11. NTP clients will recognize that and cease to use the unsynchronized server.

RS-232 Serial I/O Port Signal Definitions

DB9M Pin on Præcis Cntp	Signal Name
1	Data Carrier Detect (DCD)
2	Receive Data (RX)
3	Transmit Data (TX)
4	Data Terminal Ready (DTR)
5	Ground
6	Data Set Ready (DSR)
7	Request To Send (RTS)
8	Clear To Send (CTS)
9	Ring Indicator (RI)

Null Modem Adapter Cable

In order to connect the Præcis Cntp to another computer, a null modem adapter must be used. The provided adapter cable is wired this way:

DB9F Pin on Adapter	DB9F Pin on Adapter
1	4
2	3
3	2
4	1
5	5
7	8
8	7
9	9

Pin 6 is not connected.

Upgrading the Firmware

Periodically, EndRun Technologies will make bug fixes and enhancements to our products available for download from our website. All such downloads are freely available to our customers, without charge. After you have downloaded the appropriate FLASH binary image file from the EndRun Technologies website, you are ready to perform the upgrade to your Præcis Cntp.

The firmware consists of two FLASH binary image files. One of these is the firmware for the Præcis Cntp itself. This firmware executes on the IBM-compatible single board computer and contains the embedded Linux operating system and NTP specific application software. The other file is the firmware for the CDMA time and frequency subsystem. This firmware executes in the Præcis Cntp CDMA time and frequency engine. Each of these files may be upgraded independently.

What You Need To Perform the Upgrade

You will need to use **ftp** or **scp** to transfer the FLASH binary image file(s) to the Præcis Cntp. This means that you must place the previously downloaded file(s) in a place on your network which is accessible to the Præcis Cntp.

Performing the Præcis Cntp Upgrade

There are two FLASH disk partitions which hold the compressed root file system images. These are normally unmounted. When an upgrade is to be performed they are mounted at `/rootfs_0` and `/rootfs_1`. The factory shipped image is always stored in the first of these partitions as `/rootfs_0/rootfsX.XX.gz`. Where X.XX is the factory shipped version. It is stored with the immutable attribute set so that even `root` cannot inadvertently delete it or overwrite it. When performing an upgrade, you will be copying the new image to the partition that will be mounted on `/rootfs_1`.

To perform the upgrade, log in as the *root* user to the Præcis Cntp using the local console serial I/O port, **telnet** or **ssh** and perform these operations:

First enable the upgrade partition by issuing this command at the shell prompt:

```
cntpenableupgrade
```

This command will mount the FLASH disk root file system partitions. Now change the working directory to the upgrade partition:

```
cd /rootfs_1
```

Now remove any previously installed root file system image that may be on the upgrade partition:

```
rm /rootfs_1/*.gz
```

If you are using **ftp** to perform the upgrade, transfer the previously downloaded file using *binary* transfer mode from the remote host to the working directory, */rootfs_1* using FTP (substitute the name of the root file system image that your are installing for *rootfsupgrade.gz*):

```
ftp remote_host      {perform ftp login on remote host}
bin                  {set transfer mode to binary}
get rootfsupgrade.gz {transfer the file}
quit                 {close the ftp session after the transfer }
```

If you are using **ssh**, you may open another command window on the remote computer and securely transfer the root file system image using **scp** from the remote computer. A command like this could be used:

```
scp -p rootfsupgrade.gz root@cntp.your.domain:/rootfs_1
```

Now you must leave the */rootfs_1* directory in order to execute the **updatelilo** command and complete the upgrade:

```
cd /root
```

Update the LILO configuration by executing this shell script (substitute the name of the root file system image that your are installing for *rootfsupgrade.gz*):

```
/boot/updatelilo 1 rootfsupgrade.gz
```

You should see these lines displayed if the update is successful:

```
Added PraecisCntp_0
Added PraecisCntp_1 *
```

Unmounting root file system partitions now. Run `cntpenableupgrade` again to remount them, should you need to re-run `updatelilo`.

The trailing asterisk following the second line indicates that the LILO configuration file is set to default to the new PraecisCntp_1 root file system that you just installed on `/rootfs_1`. Now reboot the system by issuing this command at the shell prompt:

```
shutdown -r now
```

Wait about 30 seconds for the system to shutdown and re-boot. Then log in to the Praecis Cntp using `telnet` or `ssh`. If all has gone well, you should be able to log in the usual way. After you have entered your password, the system message will be displayed. You should notice that it now indicates the software version and date of the upgrade that you previously downloaded. You can also check this at any time by issuing

```
cntpversion
```

which will cause the system message to be re-displayed.

You can also check to see which root file system image the system is currently booted under by issuing this command at the shell prompt:

```
cntprootfs
```

Which should cause this to be printed to the console:

```
BOOT_IMAGE=PraecisCntp_1
```

If so, and your unit seems to be operating normally, you have successfully completed the upgrade. If your unit does not boot up successfully, and you are not able to `telnet` or `ssh` into the system after 30 seconds, then there has been some kind of problem with the upgrade. It is possible that the file downloaded was corrupt or that you forgot to set your FTP download file mode to binary when downloading the file--either from the EndRun Technologies website or when transferring it to the Praecis Cntp.

Recovering from a Failed Upgrade

To restore your Praecis Cntp to a bootable state using the factory root file system, you must use the serial I/O port and re-boot the Praecis Cntp by cycling the power. Refer to Chapter 1 – *Connect the Serial I/O Port* and *Test the Serial I/O Port* for setup details. When you have connected your terminal to the serial I/O port, apply power to the Praecis Cntp.

Pay close attention to the terminal window while the unit is re-booting. When the LILO prompt is displayed, you must press the ESC key once on your keyboard within five seconds to let LILO know that you are going to enter the name of a root file system label that it should boot in place of the default. Now type

```
PraecisCntp_0
```

This tells LILO to boot the factory root file system. Now watch the rest of the boot process to make sure that you have successfully recovered from the failed upgrade. If the system boots normally, then you should resolve the problems with the previous upgrade and re-perform it.

Performing the CDMA Upgrade

To perform this upgrade, log in as the *root* user to the Praecis Cntp using either the local console serial I/O port, **telnet** or **ssh** and perform these operations:

Change the working directory to the */tmp* directory:

```
cd /tmp
```

If you are using **ftp** to perform the upgrade, transfer the previously downloaded file using *binary* transfer mode from the remote host to the working directory, */tmp* (substitute the name of the CDMA sub-system image that you are installing for *cdmaupgrade.bin*):

```
ftp remote_host      {perform ftp login on remote host}
bin                  {set transfer mode to binary}
get cdmaupgrade.bin  {transfer the file}
quit                 {close the ftp session after the transfer }
```

If you are using **ssh**, you may open another command window on the remote computer and securely transfer the CDMA sub-system image to the */tmp* directory using **scp** from the remote computer. A command like this could be used:

```
scp -p cdmaupgrade.bin root@cntp.your.domain:/tmp
```

Now issue the following command to the Praecis Cntp CDMA engine to initiate the upload:

```
echo -e "upload\r" > /dev/ttyS0
```

This command tells the Praecis Cntp CDMA engine to enter the ‘waiting for download’ mode. Now issue this command to start the transfer of the binary file using the XMODEM protocol:

```
lsz -Xk cdmaupgrade.bin < /dev/ttyS0 > /dev/ttyS0 2>&1
```

After issuing this command you will have to wait for about one minute for the transfer to complete before the prompt will be re-displayed. There will be no diagnostic error messages displayed if the upload is successful. Following a successful upload, you will see the front panel ALARM and LOCK LEDs go through the start-up sequence.

After about one minute, you should query the CDMA firmware version using the command:

```
cdmaversion
```

The new version information should be displayed.

Problems with the CDMA Upgrade

Should you have difficulties with the upgrade due to a corrupt file, power failure during upload, or other accident, do not be alarmed. Even though you may have lost the existing application program, the Præcis Cntp CDMA engine boot loader program will remain intact. On boot up, it will check to see if a valid application program is in the FLASH memory. If there is not, it will immediately go into the 'waiting for download' mode. You may verify this by issuing this command:

```
cat < /dev/ttyS0
```

You should now see the 'C' character being received every three seconds. This is the character that the Præcis Cntp CDMA engine boot loader sends to indicate to the XMODEM utility that it is waiting for a download. You may now re-try the upload procedure, assuming that you have corrected any original problem with the binary file. First kill the **cat** command by typing CTRL-C. You should see a command prompt. Now issue this command to start the transfer of the binary file using the XMODEM protocol:

```
lsz -Xk cdmaupgrade.bin < /dev/ttyS0 > /dev/ttyS0 2>&1
```




Simple Network Management Protocol

Your *Præcis Cntp* includes the University of California at Davis (UCD)-SNMP version 4.2.5 implementation of a SNMP agent, **snmpd** and a SNMP notification/trap generation utility, **snmptrap**. It supports all versions of the protocol in use today: SNMPv1 (the original Internet standard), SNMPv2c (never reached standard status, often called “community SNMP”) and SNMPv3 (the latest Internet standard).

The UCD-SNMP project has its roots in the Carnegie-Mellon University SNMP implementation. For more detailed information about the UCD-SNMP project and to obtain management software and detailed configuration information, you can visit this website:

<http://www.net-snmp.org>

An excellent book which describes operation and configuration of various SNMP managers and agents, including the UCD-SNMP implementations, is available from O'Reilly & Associates:

Essential SNMP, Mauro & Schmidt, O'Reilly & Associates, 2001

If you are planning to operate with SNMPv3, it is highly recommended that you make use of both of these resources to familiarize yourself with the agent configuration concepts.

SNMPv3 Security

Prior to SNMPv3, SNMP had definite security inadequacies due to using two community names in a manner analogous to passwords that were transmitted over the network as clear text. In addition, since no mechanism existed for authenticating or encrypting session data, any number of man-in-the-middle data corruption/replacement exploits were possible in addition to plain old snooping to learn the community names. SNMPv3

implements the User-based Security Model (USM) defined in RFC-2274 which employs modern cryptographic technologies to both authenticate multiple users and to encrypt their session data for privacy, much in the same way that SSH does for remote login shell users.

In addition, it implements the View-based Access Control Model (VACM) defined in RFC-2275. This RFC defines mechanisms for limiting the access of multiple users having various security levels (no authentication, authentication or authentication plus privacy) to specific “views” of the Structure of Management Information (SMI) object tree.

Enterprise Management Information Base (MIB)

In addition to providing the SNMP variables contained in MIB-II as described in RFC-1213, EndRun Technologies has implemented an enterprise MIB using the syntax of the SMI version 2 (SMIV2) as described in RFC-2578:

ENDRUNTECHNOLOGIES-MIB

Which is located on your Præcis Cntp in this ASCII file:

```
/usr/local/share/snmp/mibs/ENDRUNTECHNOLOGIES-MIB.txt
```

In addition to a complete set of NTP and CDMA status objects, the MIB defines four SMIV2 notification objects:

- NTP Leap Indicator Bits status change
- NTP Stratum change
- CDMA Fault Status change
- CDMA Time Figure of Merit change

Invocation of the SNMP daemon

The SNMP daemon, `snmpd` is started from the `/etc/rc.d/rc.local` system start-up script with this line:

```
snmpd -s -c /etc/snmpd.conf
```

By default, it will listen on port 161 for SNMP queries from the network management system. If you would like to have it listen on another port, you could edit the file by adding `-p port` to the end of this line, where `port` is the number of the port you would like for the agent to listen on. If you would like to disable starting of the `snmpd` daemon altogether, you can either remove this line or place a `#` character at the beginning of the line so that it will not be executed. (A very compact editor with WordStar command keystrokes is available on the system for this purpose: `edit`. If you start `edit` without

giving it a file name to open, it will display its help screen, showing the supported key-strokes.)

IMPORTANT

After editing */etc/rc.d/rc.local*, you must copy it to the */boot/etc/rc.d* directory and re-boot the system. It is very important to retain the access mode for the file, so be sure to use `cp -p` when performing the copy. During the boot process, the files contained in the */boot/etc/rc.d* directory are copied to the working */etc/rc.d* directory on the system RAM disk. In this way the factory defaults are over written.

Quick Start Configuration – SNMPv1/v2c

You should be able to compile the ENDRUNTECHNOLOGIES-MIB file on your SNMP management system and access the variables defined therein. The factory default community names are “Præcis” for the read-only community and “endrun_1” for the read-write community. This is all that is required for operation under v1 and v2c of SNMP. You can, and should, change the default community names by editing */etc/snmpd.conf* and modifying these two lines:

```
rwcommunity   endrun_1
rocommunity   Praecis
```

Configuring SNMPv1 Trap Generation

To have your Præcis Cntp send SNMPv1 traps (RFC-1215) you must configure the community and destination for SNMPv1 traps by uncommenting and editing this line in */etc/snmpd.conf*:

```
trapsink      xxx.xxx.xxx.xxx trapcommunity trapport
```

where `trapcommunity` should be replaced by your community, and `xxx.xxx.xxx.xxx` is the IP address or hostname of the destination host for receiving the traps generated by the Præcis Cntp. By default, the trap will be sent to port 162. You may optionally add another parameter, `trapport` to the end of the above line to override the default port setting. Otherwise leave it blank.

Note: Though the agent will recognize multiple `trapsink` lines within */etc/snmpd.conf* and send the generic SNMP coldStart or authenticationFailure traps to each destination, the enterprise trap generation mechanism of the Præcis Cntp will only send a trap to the last declared `trapsink` in the file.

Configuring SNMPv2c Notifications and Informs

To have your Præcis Cntp send SNMPv2c notifications (SMIv2, RFC-2578) or informs, you must configure the communities and destinations by uncommenting and editing one or both of these lines in */etc/snmpd.conf*:

```
trap2sink    xxx.xxx.xxx.xxx trap2community trap2port
informsink   xxx.xxx.xxx.xxx informcommunity informport
```

where `trap2community` and `informcommunity` should be replaced by your communities, and `xxx.xxx.xxx.xxx` is the IP address or hostname of the destination host for receiving the notifications or informs generated by the Præcis Cntp. By default, the v2c trap or inform will be sent to port 162. You may optionally add another parameter, `trap2port` or `informport` to the ends of the above lines to override the default port setting. Otherwise leave it blank.

Note: Though the agent will recognize multiple `trap2sink` or `informsink` lines within */etc/snmpd.conf* and send the generic SNMP coldStart or authenticationFailure notifications and informs to each destination, the enterprise notification/inform generation mechanism of the Præcis Cntp will only send a notification to the last declared `trap2sink` and an inform to the last declared `informsink` in the file.

IMPORTANT

After editing */etc/snmpd.conf*, you must copy it to the */boot/etc* directory and re-boot the system. It is very important to retain the access mode for the file (i.e. readable only by *root*), so be sure to use `cp -p` when performing the copy. During the boot process, the files contained in the */boot/etc* directory are copied to the working */etc* directory on the system RAM disk. In this way the factory defaults are over written.

Configuration of SNMPv3

If you are planning to use SNMPv3, you should definitely make use of the two resources mentioned previously (UCD-SNMP website and *Essential SNMP*) and study them carefully. There are rather elaborate configuration options available when you are using v3. The instruction presented here will give you the flavor of the configuration but definitely not the full scope of possibilities. To access your Præcis Cntp via v3 of SNMP, you will have to configure two files:

```
/etc/snmpd.conf
/boot/ucd-snmp/snmpd.conf
```

The first file contains static configuration parameters that the agent uses to control access and to determine where to send notifications/traps. Other aspects of the agent's

operation are also configurable in this file, but you should not need to modify those. To use the SNMPv3 capabilities of the Præcis Cntp, you must first set up user information and access limits for those users in `/etc/snmpd.conf`. Uncomment and edit these two lines to define your v3 users and their access parameters:

```
rwuser root    priv .1
rouser ntpuser auth .1.3.6.1.4.1.13827
```

The first line defines a SNMPv3 read-write user `root` whose minimum security level will be authenticated and encrypted for privacy (choices are `noauth`, `auth` and `priv`), and who will have read-write access to the entire `iso(1)` branch of the SMI object tree. The second line defines a SNMPv3 read-only user `ntpuser` whose minimum security level will be authenticated but not encrypted, and who will have read-only access to the entire `iso(1).org(3).dod(6).internet(1).private(4).enterprises(1).endRunTechnologiesMIB(13827)` branch of the SMI object tree. After adding the user lines to `/etc/snmpd.conf`, copy it to the `/boot/etc` directory using `cp -p`.

The second file is located on the non-volatile FLASH disk and is used by the SNMP agent to store “persistent data” that may be dynamic in nature. This may include the values of the MIB-II variables `sysLocation`, `sysContact` and `sysName` as well as any configured SNMPv3 user crypto keys. In order to use SNMPv3, you must configure user keys in this file for each SNMPv3 user that you have set up in `/etc/snmpd.conf`. To do this, you must add lines to `/boot/ucd-snmp/snmpd.conf` like these for each user:

```
createUser root    MD5 endrun_1 DES endrun_1
createUser ntpuser SHA Praecis0
```

The first line will cause the agent, `snmpd` to create a user `root` who may be authenticated via Message Digest Algorithm 5 (MD5) with password `endrun_1` and may use the Data Encryption Standard (DES) to encrypt the session data with passphrase `endrun_1`. The second line will cause a user `ntpuser` to be created who may be authenticated using the Secure Hash Algorithm (SHA) with password `Praecis0`. Passwords and passphrases must have a *minimum* of 8 characters, or you will not be able to be authenticated.

IMPORTANT

You must kill the `snmpd` process prior to editing `/boot/ucd-snmp/snmpd.conf`. Otherwise, the secret key creation may not complete properly. Issue the command `ps -e` to have the operating system display the list of running processes. Look for the PID of the `snmpd` process and issue the `kill` command to stop it. For example, if the PID listed for the `snmpd` process is 53, then you would issue this command: `kill 53`. You can verify that the process was terminated by re-issuing the `ps -e` command.

After re-booting, the agent will read the `/boot/ucd-snmp/snmpd.conf` configuration file and compute secret key(s) for each of the users and delete the `createUser` lines from the file. It will then write the secret key(s) to the file. These lines begin with the string, `usmUser`. In this way, un-encrypted passwords are not stored on the system.

IMPORTANT

The encryption algorithms used by the agent are dependent upon the IP address of the Præcis Cntp. Because of this, new keys must be generated anytime your Præcis Cntp's IP address is changed. It also means that you cannot use the same `/boot/ucd-snmp/snmpd.conf` file with multiple Præcis Cntp units. To generate new keys, stop the `snmpd` process, delete the existing `usmUser` key lines from the file and then add new `createUser` lines. Then re-boot the system.

This example gives the simplest configuration to begin using SNMPv3 but doesn't make use of the full capabilities of the VACM in defining groups and views for fine-grained access control. The factory default `/etc/snmpd.conf` file contains commented blocks of lines that can be uncommented to give you a basic configuration that uses the User-based Security Model (USM) described in RFC-2274 and the View-based Access Control Model (VACM) described in RFC-2275. The comments included in the file should help you in modifying it for your specific requirements.



Security

Your Præcis Cntp incorporates several important security features to prevent unauthorized tampering with its operation. Many of these are standard multiple-user access control features of the underlying Linux operating system which controls the Præcis Cntp. Others are provided by the additional protocol servers selected for inclusion in your Præcis Cntp, and the way that they are configured.

Secure user authentication and session privacy while performing routine monitoring and maintenance tasks are provided by the OpenSSH implementations of the “secure shell” daemon, **sshd** and its companion “secure copy” utility, **scp**. The UCD-SNMP implementation of the Simple Network Management Protocol (SNMP) daemon, **snmpd** conforms to the latest Internet standard, known as SNMPv3, which also supports secure user authentication and session privacy. In addition, the Network Time Protocol daemon, **ntpd** supports client-server authentication security measures to deter spoofing of NTP clients by rogue NTP servers. This appendix describes these security measures and gives the advanced network administrator information that will allow custom configuration to fit specific security needs.

Linux Operating System

The embedded Linux operating system running in the Præcis Cntp is based on kernel version 2.2.13 and version 7 of the Slackware Linux distribution. As such it supports a complete set of security provisions:

- System passwords are kept in an encrypted file, */etc/shadow* which is not accessible by users other than *root*.
- Direct *root* logins are only permitted on the local RS-232 console or via SSH
- The secure copy utility, **scp** eliminates the need to use the insecure **ftp** protocol for transferring program updates to the Præcis Cntp

- Access via SNMP is configurable to provide the security of the latest version 3 Internet standard which supports both view-based access control and user-based security using modern encryption techniques. Previous versions v1 and v2c supported access control essentially via passwords transmitted over the network in plain text. Refer to *Appendix C – Simple Network Management Protocol* which is dedicated to configuration of SNMP for details.
- Individual host access to protocol server daemons such as **in.telnetd**, **snmpd** or **sshd** may be controlled by the **tcpd** daemon and */etc/hosts.allow* and */etc/hosts.deny*
- Risky protocols like TIME, DAYTIME and TELNET may be completely disabled by configuration of the **inetd** super-server daemon.

The last two topics are supported on the Præcis Cntp by a pair of shell scripts which ease configuration for the inexperienced user of Unix-like operating systems. These are **accessconfig** and **inetdconfig**.

accessconfig modifies two files which are used by **tcpd** and the standalone daemon, **snmpd** to determine whether or not to grant access to a requesting host: */etc/hosts.allow* and */etc/hosts.deny*. These two files may contain configuration information for a number of protocol servers, but in the Præcis Cntp only access control to the protocol server daemons **in.telnetd**, **sshd** and **snmpd** is configured.

As shipped from the factory, these two files are empty. When the user runs **accessconfig**, these lines are added to the */etc/hosts.deny* file:

```
in.telnetd: ALL
sshd: ALL
snmpd: ALL
```

This tells **tcpd** to deny access to **in.telnetd** and **sshd** to all hosts not listed in the */etc/hosts.allow* file. The **snmpd** daemon also parses this file itself prior to granting access to a requesting host. Then the user is prompted to enter a list of hosts that will be granted access to **in.telnetd**, **sshd** and **snmpd**. These appear in the */etc/hosts.allow* as lines like this:

```
in.telnetd: 192.168.1.2, 192.168.1.3
sshd: 192.168.1.2, 192.168.1.3
snmpd: 192.168.1.2, 192.168.1.3
```

This simple shell script handles the needs of most users, however the syntax of these two files supports elaborate configuration possibilities which are beyond the capabilities of this simple shell script. Advanced users who need these capabilities will need to edit these two files directly and then copy them to the */boot/etc* directory. (A very compact editor with WordStar command keystrokes is available on the system for this purpose:

edit. If you start **edit** without giving it a file name to open, it will display its help screen, showing the supported keystrokes.) Be careful to maintain the proper ownership and access permissions by using **cp -p** when copying the files.

inetdconfig modifies the */etc/inetd.conf* file which is read by **inetd** to start-up various protocol server daemons when requests from remote hosts are received. Currently, four servers are configurable via **inetdconfig**: **TIME** and **DAYTIME**, whose daemons are contained within the **inetd** daemon itself, and **in.telnetd** and **sshd**. Any one or all of these may be enabled or disabled for start-up.

OpenSSH

The secure shell protocol server running in the Præcis Cntp is based on the portable OpenSSH version 3.4p1 for Linux. As such it supports both SSH1 and SSH2 protocol versions. For more information about this protocol and to obtain client software, refer to the OpenSSH website:

www.openssh.com

An excellent book which describes operation and configuration of the various SSH implementations, including OpenSSH is available from O'Reilly & Associates:

SSH, The Secure Shell, Barrett & Silverman, O'Reilly & Associates, 2001

In the interest of conserving scarce system memory resources, only the secure shell server daemon, **sshd** and the secure copy utility, **scp** are implemented in the Præcis Cntp. This means that users on remote hosts may log in to the Præcis Cntp via an **ssh** client, but users logged in on the Præcis Cntp are unable to log in to a remote host via **ssh**. Since **scp** runs in concert with an **ssh** client, the same limitations exist for its use, i.e. users on remote hosts may transfer files to and from the Præcis Cntp via **scp** over **ssh** but users logged in on the Præcis Cntp are unable to transfer files to and from a remote host via **scp** over **ssh**.

The factory configuration contains a complete set of security keys for both SSH1 and SSH2 versions of the protocol. RSA keys are supported by both versions, and DSA keys are supported when using the SSH2 version.

In addition, the Præcis Cntp is factory configured with a set of public keys for password-less, public key authentication of the root user. To use this capability, the corresponding set of private keys for each of the two SSH versions are provided in the */boot/root* directory of the Præcis Cntp. Three files contain these keys: *identity* (SSH1), *id_rsa* (SSH2) and *id_dsa* (SSH2). These must be copied to the user's *~/.ssh* directory on their remote computer. (Be careful to maintain the proper ownership and access permissions by us-

ing `cp -p` when copying the files. They *must* be readable only by *root*.) The corresponding public keys are by factory default resident in the `/root/.ssh` directory of the Præcis Cntp. Two files contain these keys: `authorized_keys` (SSH1) and `authorized_keys2` (SSH2).

Since the provided private keys are not passphrase protected, the user should create a new set of keys after verifying operation with the factory default key sets. After creating the new keys, the public keys should be copied to the `/boot/root/.ssh` directory of the Præcis Cntp. At boot time, the Præcis Cntp will copy these to the actual `/root/.ssh` directory of the system ramdisk, thereby replacing the factory default set of public keys.

Advanced users wishing to modify the configuration of the `sshd` daemon should edit the `/etc/sshd_config` file and then copy it to the `/boot/etc` directory of the Præcis Cntp. Be careful to maintain the proper ownership and access permissions by using `cp -p` when copying the file. At boot time, it will be copied to the `/etc` directory of the system ramdisk, thereby replacing the factory default configuration file.

Network Time Protocol

The NTP implementation in the Præcis Cntp is built from version 4.0.99k of the standard distribution from the www.ntp.org site. It has been patched with the security update 4.0.99k23 which corrects a security flaw in the remote control sub-system. By factory default, remote control of the NTP daemon `ntpd` is disabled. Query-only operation is supported from the two NTP companion utilities `ntpq` and `ntpdcc`.

Control via these two utilities is disabled in the `/etc/ntp.conf` file in two ways. First, MD5 authentication keys are not defined for control operation via a `requestkey` or `controlkey` declaration. Second, this default address restriction line is present in the file:

```
restrict default notrust nomodify
```

This line eliminates control access from ALL hosts. Query access is not affected by this restriction. Knowledgeable NTP users who would like to customize the security aspects of the configuration of the NTP daemon in the Præcis Cntp should edit the `/etc/ntp.conf` file directly and then copy it to the `/boot/etc` directory. Be sure to retain the ownership and permissions of the original file by using `cp -p` when performing the copy.

CAUTION

If you are planning to make changes to the `/etc/ntp.conf` file, you must not restrict query access from the local host to the NTP daemon. Various system monitoring processes running on the system require this access.



Lithium Battery Replacement

Your Præcis Cntp incorporates a lithium battery on its IBM-PC compatible single board computer sub-system component. This battery is *not* user servicable and your Præcis Cntp should be returned to the factory should its replacement become necessary.



CAUTION

Danger of explosion if battery is incorrectly replaced..

Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.



Specifications

CDMA Receiver:

- AMPS Mobile Receive Band – 869-894 MHz
- TIA/EIA IS-95 CDMA Pilot and Sync channels.

Antenna:

- SMA jack on rear panel, $Z_{in} = 50\Omega$.
- 824-896 MHz, magnetic-base $\lambda/2$ monopole with integral 12 ft. RG-58/U cable and SMA plug.

Local Oscillator: TCXO. OCXO or Rubidium (options).

Time to Lock: < 5 minutes, typical.

Network I/O (rear panel RJ-45 jack): 10/100Base-T ethernet

System Status Indicators (front panel):

- **Lock LED:** green indicator that pulses to indicate the current CDMA acquisition and lock status.
- **Link LED:** amber indicator that illuminates when the ethernet connection is up.
- **Activity LED:** amber indicator that flashes when ethernet packets are received or transmitted.
- **Alarm LED:** red indicator that illuminates when a serious fault condition exists.

Linux Maintenance Console:

RS-232 serial I/O on rear panel DB9M jack for secure, local terminal access. Parameters fixed at 19200 baud, 8 data bits, no parity, 1 stop bit. For communication with another computer, 2 meter DB9F—DB9F null modem adapter cable is included.

NTP Client Synchronization Accuracy:

Network factors can limit NTP client synchronization accuracy to .5-2 ms, typical. Timestamping accuracy is maintained to less than 100 us while processing hundreds of NTP packets per second.

Supported Protocols:


- SNTP, NTP v2, v3, v4 and broadcast/multicast mode; MD5 authentication
- SSH server with “secure copy” utility, SCP (Open SSH version 3.4p1)
- SNMP v1, v2c, v3 with Enterprise MIB
- MD5 authentication
- TIME and DAYTIME server
- TELNET client/server
- FTP client
- DHCP client

Optional Timing Outputs (rear panel BNC jacks):

- **1 PPS:** 1 ms wide, positive TTL pulse @ 50Ω.
Accuracy: < 10 microseconds to UTC when locked, typical. Range to base station may degrade this in fringe area applications, due to increased propagation delay.
Stability: TDEV < 50 ns, $\tau < 10^4$ seconds.
- **Time Code:** 1 Vrms @ 50Ω.
Format: IRIG-B122

Optional Frequency Output (rear panel BNC jack):

- **10 MPPS:** TTL squarewave @ 50Ω.
Accuracy: < 1×10^{-11} to UTC for 24 hour averaging times when locked.
Stability:



Additional Optional Time/Frequency Outputs (rear panel BNC jacks):

- **10 MHz:** 1Vrms sinewave @ 50Ω, harmonics < -45 dBc
- **5 MHz:** 1Vrms sinewave @ 50Ω, harmonics < -45 dBc
- **1 MHz:** 1Vrms sinewave @ 50Ω, harmonics < -45 dBc
- **5 MPPS:** TTL squarewave @ 50Ω
- **1 MPPS:** TTL squarewave @ 50Ω
- **Time Code TTL:** IRIG-B022 DC-shift TTL @ 50Ω

Power:

- 85-270 VAC, 47-63 Hz, .5 A Max. @ 120 VAC, .25 A Max. @ 240 VAC
- 110-370 VDC, 0.5A Max @ 120 VDC
- 3-Pin IEC 320 on rear panel, 2 meter line cord is included.

Size:

- **Chassis:** 1.75”H x 17.0”W x 10.75”D
- **Antenna:** 14” H x 2.0” Dia. at base

Weight: < 5 lb. (2.70 kg.)

Environmental:

- **Temperature:** 0° to +50°C
- **Humidity:** 0 to 95%, non-condensing

CE/FCC Compliance: RTTE Directive 99/5/EC
 Low Voltage Directive 73/23/EC
 EMC Directive 89/336/EC
 With Amendment 93/68/EC

Supplementary Compliance Data:

- **Safety:** EN 60950;1992, A1,A2: 1993, A3: 1995, A4: 1997, A11:1998
- **EMC:** EN 55024 (1998), EN61000-3-2 (1995 w/A1 & A2:98), EN61000-3-3 (1995 w/A1:98), EN55022 (1998 w/A1:00) Class A, VCCI (April 2000) Class A, CISPR 22 (1997) Class A, FCC Part 15 Subpart B Section 15.109 Class A, ICES-003 Class A (ANSI C63.4 1992), AS/NZS 3548 (w/A1 & A2: 97) Class A

